Contact: 866-275-6964

support@ni.com



Manufacturer: National Instruments

## **Board Assembly Part Numbers** (Refer to Procedure 1 for identification procedure):

	<u>, `</u>
Part Number and Revision	Description
191852A-02(L) or later	PCI-6122 (4 Ch, 32 MB)
191852A-03(L) or later	PCI-6123 (8 Ch, 64 MB)
191852A-04(L) or later	PCI-6123 (8 Ch, 32 MB)
191855A-02(L) or later	PXI-6122 (4 Ch, 32 MB)
191855A-03(L) or later	PXI-6123 (8 Ch, 64 MB)
191855A-04(L) or later	PXI-6123 (8 Ch, 32 MB)
191215A-02(L) or later	PCI-6132(4 Ch, 32 MB)
191215A-03(L) or later	PCI-6133 (8 Ch, 64 MB)
191215A-04(L) or later	PCI-6133 (8 Ch, 32 MB)
188611D-02(L) or later	PXI-6132 (4 Ch, 32 MB)
188611D-03(L) or later	PXI-6133 (8 Ch, 64 MB)
188611D-04(L) or later	PXI-6133 (8 Ch, 32 MB)

# **Volatile Memory**

			Battery	$User^{I}$	System	Sanitization
Target Data	Туре	Size	Васкир	Accessible	Accessible	Procedure
Glue logic	FPGA	Intel EP20K160E	No	No	Yes	Cycle Power
Glue logic	CPLD	Xilinx XC95144XL	No	No	No	Cycle Power
Glue logic	FPGA	Xilinx XC2S100	No	No	Yes	Cycle Power

## Non-Volatile Memory (incl. Media Storage)

			Battery	User	System	Sanitization
Target Data	Type	Size	Backup	Accessible	Accessible	Procedure
Calibration information	EEPROM	1 kB	No			
<ul> <li>Calibration metadata</li> </ul>				Yes	Yes	Procedure 2
<ul> <li>Calibration data<sup>2</sup></li> </ul>				No	Yes	None
Device configuration	EEPROM	8 kB		No	Yes	None

<sup>&</sup>lt;sup>1</sup> Refer to *Terms and Definitions* section for clarification of *User* and *System Accessible* 

<sup>&</sup>lt;sup>2</sup> Calibration constants that are stored on the device include information for the device's full operating range. Any implications resulting from partial self-calibration can be eliminated by running the full self-calibration procedure.




### **Procedures**


#### **Procedure 1–Board Assembly Part Number Identification:**

To determine the Board Assembly Part Number and Revision, refer to the "P/N" label applied to the surface of your product as shown below. The Assembly Part Number should be formatted as "P/N: #####a-vvL" where "a" is the letter revision of the Board Assembly (eg. A, B, C...) and the "vv" is the type identifier. If the product is RoHS compliant, "L" can be found at the end of the part number.


#### PCI-6122/23/32/33 – Primary Side



PXI-6122/23 – Secondary Side



PXI-6132/33 – Secondary Side



Contact: 866-275-6964

support@ni.com

#### **Procedure 2–Calibration InformationEEPROM (Calibration Metadata):**

The user-accessible areas of the Calibration Information EEPROM are exposed through a calibration Applications Programming Interface (API) in LabVIEW. To clear the calibration meta-data area, complete the following steps:

1. The user-accessible areas of the Device Configuration EEPROM can be cleared using the NI DAQmx API. For instructions on how to clear these areas, go to <a href="www.ni.com/info">www.ni.com/info</a> and enter info code DAQmxLOV

Contact: 866-275-6964

support@ni.com



#### **Terms and Definitions**

#### **Cycle Power:**

The process of completely removing power from the device and its components and allowing for adequate discharge. This process includes a complete shutdown of the PC and/or chassis containing the device; a reboot is not sufficient for the completion of this process.

### **Volatile Memory:**

Requires power to maintain the stored information. When power is removed from this memory, its contents are lost. This type of memory typically contains application specific data such as capture waveforms.

### **Non-Volatile Memory:**

Power is not required to maintain the stored information. Device retains its contents when power is removed. This type of memory typically contains information necessary to boot, configure, or calibrate the product or may include device power up states.

#### **User Accessible:**

The component is read and/or write addressable such that a user can store arbitrary information to the component from the host using a publicly distributed NI tool, such as a Driver API, the System Configuration API, or MAX.

#### **System Accessible:**

The component is read and/or write addressable from the host without the need to physically alter the product.

### **Clearing:**

Per NIST Special Publication 800-88 Revision 1, "clearing" is a logical technique to sanitize data in all User Accessible storage locations for protection against simple non-invasive data recovery techniques using the same interface available to the user; typically applied through the standard read and write commands to the storage device.

#### **Sanitization:**

Per NIST Special Publication 800-88 Revision 1, "sanitization" is a process to render access to "Target Data" on the media infeasible for a given level of effort. In this document, clearing is the degree of sanitization described.