

Manufacturer: National Instruments

Board Assembly Part Numbers (Refer to Procedure 1 for identification procedure):

Part Number and Revision	Description
146620A-01L or later	PXIe-5763 FlexRIO AC Digitizer, KU035 FPGA
146620A-02L or later	PXIe-5763 FlexRIO AC Digitizer, KU040 FPGA, 4GB DRAM
146620A-03L or later	PXIe-5763 FlexRIO AC Digitizer, KU060 FPGA, 4GB DRAM
146621A-01L or later	PXIe-5763 FlexRIO DC Digitizer, KU035 FPGA
146621A-02L or later	PXIe-5763 FlexRIO DC Digitizer, KU040 FPGA, 4GB DRAM
146621A-03L or later	PXIe-5763 FlexRIO DC Digitizer, KU060 FPGA, 4GB DRAM

Volatile Memory

<i>Target Data</i>	<i>Type</i>	<i>Size</i>	<i>Battery Backup</i>	<i>User¹ Accessible</i>	<i>System Accessible</i>	<i>Sanitization Procedure</i>
Data storage (PN -02 and -03 only)	DRAM	4GB	No	Yes	Yes	Cycle power
User FPGA Bitfile Storage	SDRAM	256Mb	No	Yes	Yes	Cycle power
Customer Program	UltraScale FPGA	KU035, KU040 or KU060	No	Yes	Yes	Cycle power

Non-Volatile Memory (*incl. Media Storage*)

<i>Target Data</i>	<i>Type</i>	<i>Size</i>	<i>Battery Backup</i>	<i>User Accessible</i>	<i>System Accessible</i>	<i>Sanitization Procedure</i>
Adapter Module Configuration	EEPROM	2KB	No	No	Yes	None
FPGA Configuration Logic	CPLD	10M04SAU169I7G	No	No	Yes	None
Calibration Constants	Flash	512Mb	No	Yes	Yes	Procedure 2

¹ Refer to *Terms and Definitions* section for clarification of *User* and *System Accessible*

Procedures

Procedure 1 – Board Assembly Part Number identification:

To determine the Board Assembly Part Number and Revision, refer to the label applied to the surface of your product. The Assembly Part Number should be formatted as “P/N: #####a-##L.

Procedure 2 – Calibration Constants Flash:

The Calibration Constants Flash can be cleared by using the FlexRIO API to overwrite the memory space with arbitrary values. To clear the flash storage with this method, complete the following steps:

1. Find and open the example LabVIEW Project “Read-Write Calibration Data” at “C:\Program Files (x86)\National Instruments\<LabVIEW>\examples\FlexRIO\System Calibration\” (replace <LabVIEW> with version of LabVIEW running on system).
 - a. Alternatively, create a new VI and drop the “Write Calibration Data” VI from the FlexRIO API palette.
2. Select your FlexRIO device from **FPGA Resource** dropdown and set **Calibration Operation** to **Write**.
3. Run VI with **Calibration Data** set to 0, or other arbitrary value, to clear values in flash memory.
4. Repeat Step 3 for entire memory space to clear entire flash memory. Set the **Read** option for the **Calibration Operation** to verify data has been cleared or to check sections of memory for other unintended values.

Terms and Definitions

Cycle Power:

The process of completely removing power from the device and its components and allowing for adequate discharge. This process includes a complete shutdown of the PC and/or chassis containing the device; a reboot is not sufficient for the completion of this process.

Volatile Memory:

Requires power to maintain the stored information. When power is removed from this memory, its contents are lost. This type of memory typically contains application specific data such as capture waveforms.

Non-Volatile Memory:

Power is not required to maintain the stored information. Device retains its contents when power is removed. This type of memory typically contains information necessary to boot, configure, or calibrate the product or may include device power up states.

User Accessible:

The component is read and/or write addressable such that a user can store arbitrary information to the component from the host using a publicly distributed NI tool, such as a Driver API, the System Configuration API, or MAX.

System Accessible:

The component is read and/or write addressable from the host without the need to physically alter the product.

Clearing:

Per *NIST Special Publication 800-88 Revision 1*, “clearing” is a logical technique to sanitize data in all User Accessible storage locations for protection against simple non-invasive data recovery techniques using the same interface available to the user; typically applied through the standard read and write commands to the storage device.

Sanitization:

Per *NIST Special Publication 800-88 Revision 1*, “sanitization” is a process to render access to “Target Data” on the media infeasible for a given level of effort. In this document, clearing is the degree of sanitization described.