

INSTALLATION GUIDE

CANopen LabVIEW Library

This installation guide contains instructions to help you install your CANopen LabVIEW Library software. Complete documentation is in the *CANopen LabVIEW Library Help*, which is available within LabVIEW's **Help** menu. The CANopen LabVIEW Library software on this CD supports Microsoft Windows, as well as NI LabVIEW Real-Time operating systems.

Install the CANopen LabVIEW Library

Before installing the CANopen LabVIEW Library, users must first log on as **Administrator** or as a user with Administrator privileges.

The CANopen LabVIEW Library setup program must have Administrator privileges because the program modifies the configuration registry of your system.

Complete the following steps to install the CANopen LabVIEW Library.

1. Insert the *CANopen LabVIEW Library* CD into your CD-ROM drive.
The installer launches if your CD-ROM drive plays data CDs automatically. If the installer does not launch automatically, navigate to the CD using Windows Explorer and launch the `autorun.exe` file from your *CANopen LabVIEW Library* CD.

2. The Installation Wizard guides you through the necessary steps to install the CANopen LabVIEW Library. You can go back and change values where appropriate by clicking the **Back** button. You can exit the setup where appropriate by clicking **Cancel**.
3. When installation is complete, click **Finish**.

Uninstalling the CANopen LabVIEW Library

Complete the following steps to remove the CANopen LabVIEW Library.

1. Run the **Add/Remove Programs** applet from the Control Panel.
2. Select **National Instruments Software**. Click the **Change** button.
3. Select **CANopen LabVIEW Library** in the list of products and click **Uninstall**.

The uninstall program removes all folders, utilities, DLLs, and registry entries associated with the CANopen LabVIEW Library. The uninstall program removes only items that the installation program installed.

If you have added anything to a directory created by the installation program, the uninstall program cannot delete that directory because it is not empty after the uninstallation. Remove any remaining components manually.

After the uninstall program completes, restart your computer.

National Instruments, NI, ni.com, and LabVIEW are trademarks of National Instruments Corporation. Refer to the *Terms of Use* section on ni.com/legal for more information about National Instruments trademarks. Other product and company names mentioned herein are trademarks or trade names of their respective companies. For patents covering National Instruments products, refer to the appropriate location: **Help>Patents** in your software, the `patents.txt` file on your CD, or ni.com/patents.