

Fieldbus

NI-FBUS™ Communications Manager Function Reference Manual

Worldwide Technical Support and Product Information

ni.com

National Instruments Corporate Headquarters

11500 North Mopac Expressway Austin, Texas 78759-3504 USA Tel: 512 683 0100

Worldwide Offices

Australia 03 9879 5166, Austria 0662 45 79 90 0, Belgium 02 757 00 20, Brazil 011 3262 3599,
Canada (Calgary) 403 274 9391, Canada (Montreal) 514 288 5722, Canada (Ottawa) 613 233 5949,
Canada (Québec) 514 694 8521, Canada (Toronto) 905 785 0085, China (Shanghai) 021 6555 7838,
China (ShenZhen) 0755 3904939, Czech Republic 02 2423 5774, Denmark 45 76 26 00, Finland 09 725 725 11,
France 01 48 14 24 24, Germany 089 741 31 30, Greece 30 1 42 96 427, Hong Kong 2645 3186,
India 91 80 535 5406, Israel 03 6393737, Italy 02 413091, Japan 03 5472 2970, Korea 02 3451 3400,
Malaysia 603 9596711, Mexico 001 800 010 0793, Netherlands 0348 433466, New Zealand 09 914 0488,
Norway 32 27 73 00, Poland 0 22 528 94 06, Portugal 351 210 311 210, Russia 095 238 7139,
Singapore 2265886, Slovenia 386 3 425 4200, South Africa 11 805 8197, Spain 91 640 0085,
Sweden 08 587 895 00, Switzerland 056 200 51 51, Taiwan 02 2528 7227, United Kingdom 01635 523545

For further support information, see the *Technical Support and Professional Services* appendix. To comment on the documentation, send email to techpubs@ni.com.

Important Information

Warranty

The media on which you receive National Instruments software are warranted not to fail to execute programming instructions, due to defects in materials and workmanship, for a period of 90 days from date of shipment, as evidenced by receipts or other documentation. National Instruments will, at its option, repair or replace software media that do not execute programming instructions if National Instruments receives notice of such defects during the warranty period. National Instruments does not warrant that the operation of the software shall be uninterrupted or error free.

A Return Material Authorization (RMA) number must be obtained from the factory and clearly marked on the outside of the package before any equipment will be accepted for warranty work. National Instruments will pay the shipping costs of returning to the owner parts which are covered by warranty.

National Instruments believes that the information in this document is accurate. The document has been carefully reviewed for technical accuracy. In the event that technical or typographical errors exist, National Instruments reserves the right to make changes to subsequent editions of this document without prior notice to holders of this edition. The reader should consult National Instruments if errors are suspected. In no event shall National Instruments be liable for any damages arising out of or related to this document or the information contained in it.

EXCEPT AS SPECIFIED HEREIN, NATIONAL INSTRUMENTS MAKES NO WARRANTIES, EXPRESS OR IMPLIED, AND SPECIFICALLY DISCLAIMS ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. CUSTOMER'S RIGHT TO RECOVER DAMAGES CAUSED BY FAULT OR NEGLIGENCE ON THE PART OF NATIONAL INSTRUMENTS SHALL BE LIMITED TO THE AMOUNT THEREOF PAID BY THE CUSTOMER. NATIONAL INSTRUMENTS WILL NOT BE LIABLE FOR DAMAGES RESULTING FROM LOSS OF DATA, PROFITS, USE OF PRODUCTS, OR INCIDENTAL OR CONSEQUENTIAL DAMAGES, EVEN IF ADVISED OF THE POSSIBILITY THEREOF. This limitation of the liability of National Instruments will apply regardless of the form of action, whether in contract or tort, including negligence. Any action against National Instruments must be brought within one year after the cause of action accrues. National Instruments shall not be liable for any delay in performance due to causes beyond its reasonable control. The warranty provided herein does not cover damages, defects, malfunctions, or service failures caused by owner's failure to follow the National Instruments installation, operation, or maintenance instructions; owner's modification of the product; owner's abuse, misuse, or negligent acts; and power failure or surges, fire, flood, accident, actions of third parties, or other events outside reasonable control.

Copyright

Under the copyright laws, this publication may not be reproduced or transmitted in any form, electronic or mechanical, including photocopying, recording, storing in an information retrieval system, or translating, in whole or in part, without the prior written consent of National Instruments Corporation.

Trademarks

National Instruments™, NI™, NI-FBUS™, and ni.com™ are trademarks of National Instruments Corporation.

Product and company names mentioned herein are trademarks or trade names of their respective companies.

Patents

For patents covering National Instruments products, refer to the appropriate location: **Help»Patents** in your software, the `patents.txt` file on your CD, or ni.com/patents.

WARNING REGARDING USE OF NATIONAL INSTRUMENTS PRODUCTS

(1) NATIONAL INSTRUMENTS PRODUCTS ARE NOT DESIGNED WITH COMPONENTS AND TESTING FOR A LEVEL OF RELIABILITY SUITABLE FOR USE IN OR IN CONNECTION WITH SURGICAL IMPLANTS OR AS CRITICAL COMPONENTS IN ANY LIFE SUPPORT SYSTEMS WHOSE FAILURE TO PERFORM CAN REASONABLY BE EXPECTED TO CAUSE SIGNIFICANT INJURY TO A HUMAN.

(2) IN ANY APPLICATION, INCLUDING THE ABOVE, RELIABILITY OF OPERATION OF THE SOFTWARE PRODUCTS CAN BE IMPAIRED BY ADVERSE FACTORS, INCLUDING BUT NOT LIMITED TO FLUCTUATIONS IN ELECTRICAL POWER SUPPLY, COMPUTER HARDWARE MALFUNCTIONS, COMPUTER OPERATING SYSTEM SOFTWARE FITNESS, FITNESS OF COMPILERS AND DEVELOPMENT SOFTWARE USED TO DEVELOP AN APPLICATION, INSTALLATION ERRORS, SOFTWARE AND HARDWARE COMPATIBILITY PROBLEMS, MALFUNCTIONS OR FAILURES OF ELECTRONIC MONITORING OR CONTROL DEVICES, TRANSIENT FAILURES OF ELECTRONIC SYSTEMS (HARDWARE AND/OR SOFTWARE), UNANTICIPATED USES OR MISUSES, OR ERRORS ON THE PART OF THE USER OR APPLICATIONS DESIGNER (ADVERSE FACTORS SUCH AS THESE ARE HEREAFTER COLLECTIVELY TERMED "SYSTEM FAILURES"). ANY APPLICATION WHERE A SYSTEM FAILURE WOULD CREATE A RISK OF HARM TO PROPERTY OR PERSONS (INCLUDING THE RISK OF BODILY INJURY AND DEATH) SHOULD NOT BE RELIANT SOLELY UPON ONE FORM OF ELECTRONIC SYSTEM DUE TO THE RISK OF SYSTEM FAILURE. TO AVOID DAMAGE, INJURY, OR DEATH, THE USER OR APPLICATION DESIGNER MUST TAKE REASONABLY PRUDENT STEPS TO PROTECT AGAINST SYSTEM FAILURES, INCLUDING BUT NOT LIMITED TO BACK-UP OR SHUT DOWN MECHANISMS. BECAUSE EACH END-USER SYSTEM IS CUSTOMIZED AND DIFFERS FROM NATIONAL INSTRUMENTS' TESTING PLATFORMS AND BECAUSE A USER OR APPLICATION DESIGNER MAY USE NATIONAL INSTRUMENTS PRODUCTS IN COMBINATION WITH OTHER PRODUCTS IN A MANNER NOT EVALUATED OR CONTEMPLATED BY NATIONAL INSTRUMENTS, THE USER OR APPLICATION DESIGNER IS ULTIMATELY RESPONSIBLE FOR VERIFYING AND VALIDATING THE SUITABILITY OF NATIONAL INSTRUMENTS PRODUCTS WHENEVER NATIONAL INSTRUMENTS PRODUCTS ARE INCORPORATED IN A SYSTEM OR APPLICATION, INCLUDING, WITHOUT LIMITATION, THE APPROPRIATE DESIGN, PROCESS AND SAFETY LEVEL OF SUCH SYSTEM OR APPLICATION.

Compliance

FCC/Canada Radio Frequency Interference Compliance*

Determining FCC Class


The Federal Communications Commission (FCC) has rules to protect wireless communications from interference. The FCC places digital electronics into two classes. These classes are known as Class A (for use in industrial-commercial locations only) or Class B (for use in residential or commercial locations). Depending on where it is operated, this product could be subject to restrictions in the FCC rules. (In Canada, the Department of Communications (DOC), of Industry Canada, regulates wireless interference in much the same way.)

Digital electronics emit weak signals during normal operation that can affect radio, television, or other wireless products. By examining the product you purchased, you can determine the FCC Class and therefore which of the two FCC/DOC Warnings apply in the following sections. (Some products may not be labeled at all for FCC; if so, the reader should then assume these are Class A devices.)

FCC Class A products only display a simple warning statement of one paragraph in length regarding interference and undesired operation. Most of our products are FCC Class A. The FCC rules have restrictions regarding the locations where FCC Class A products can be operated.

FCC Class B products display either a FCC ID code, starting with the letters **EXN**, or the FCC Class B compliance mark that appears as shown here on the right.

Consult the FCC Web site at <http://www.fcc.gov> for more information.



FCC/DOC Warnings

This equipment generates and uses radio frequency energy and, if not installed and used in strict accordance with the instructions in this manual and the CE Mark Declaration of Conformity**, may cause interference to radio and television reception. Classification requirements are the same for the Federal Communications Commission (FCC) and the Canadian Department of Communications (DOC).

Changes or modifications not expressly approved by National Instruments could void the user's authority to operate the equipment under the FCC Rules.

Class A

Federal Communications Commission

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Canadian Department of Communications

This Class A digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

Cet appareil numérique de la classe A respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

Class B

Federal Communications Commission

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Canadian Department of Communications

This Class B digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

Cet appareil numérique de la classe B respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

Compliance to EU Directives

Readers in the European Union (EU) must refer to the Manufacturer's Declaration of Conformity (DoC) for information** pertaining to the CE Mark compliance scheme. The Manufacturer includes a DoC for most every hardware product except for those bought for OEMs, if also available from an original manufacturer that also markets in the EU, or where compliance is not required as for electrically benign apparatus or cables.

To obtain the DoC for this product, click **Declaration of Conformity** at ni.com/hardref.nsf/. This Web site lists the DoCs by product family. Select the appropriate product family, followed by your product, and a link to the DoC appears in Adobe Acrobat format. Click the Acrobat icon to download or read the DoC.

* Certain exemptions may apply in the USA, see FCC Rules §15.103 **Exempted devices**, and §15.105(c). Also available in sections of CFR 47.

** The CE Mark Declaration of Conformity will contain important supplementary information and instructions for the user or installer.

Conventions

The following conventions are used in this manual:



This icon denotes a note, which alerts you to important information.

bold

Bold text denotes items that you must select or click on in the software, such as menu items and dialog box options. Bold text also denotes parameter names.

italic

Italic text denotes variables, emphasis, a cross reference, or an introduction to a key concept. This font also denotes text that is a placeholder for a word or value that you must supply.

monospace

Text in this font denotes text or characters that you should enter from the keyboard, sections of code, programming examples, and syntax examples. This font is also used for the proper names of disk drives, paths, directories, programs, subprograms, subroutines, device names, functions, operations, variables, filenames and extensions, and code excerpts.

monospace italic

Italic text in this font denotes text that is a placeholder for a word or value that you must supply.

Contents

Chapter 1

Administrative Functions

Related Documentation.....	1-1
List of Administrative Functions	1-1
nifClose	1-2
nifDownloadDomain	1-3
nifGetBlockList	1-4
nifGetDeviceList.....	1-6
nifGetInterfaceList.....	1-8
nifGetVFDList	1-10
nifOpenBlock.....	1-12
nifOpenLink.....	1-14
nifOpenPhysicalDevice	1-16
nifOpenSession	1-18
nifOpenVfd	1-19

Chapter 2

Core Fieldbus Functions

List of Core Functions	2-1
nifFreeObjectAttributes	2-2
nifFreeObjectType	2-3
nifGetObjectAttributes.....	2-4
nifGetObjectName	2-7
nifGetObjectSize.....	2-10
nifGetObjectType	2-12
nifReadObject	2-18
nifReadObjectList.....	2-21
nifWriteObject	2-24
Using Interface Macros.....	2-27

Chapter 3

Alert and Trend Functions

nifAcknowledgeAlarm.....	3-2
nifWaitAlert	3-4
nifWaitTrend.....	3-6

Appendix A

Technical Support and Professional Services

Glossary

Index

Tables

Table 1-1.	List of Administrative Functions	1-1
Table 2-1.	List of Core Functions	2-1
Table 2-2.	Object Codes for the <code>nifObjTypeList_t</code> Data Structure.....	2-14
Table 2-3.	Object Codes for the <code>nifObjTypeList_t</code> Data Structure.....	2-16
Table 2-4.	Core Function Macros.....	2-27
Table 3-1.	Alert Functions.....	3-1
Table 3-2.	Trend Function.....	3-1

Administrative Functions

For details on how NI-FBUS functions are classified and how to use them, refer to the *NI-FBUS Communications Manager User Manual*.

Related Documentation

- *Function Block Application Process, Part 1*
- *Function Block Application Process, Part 2*
- *Device Description Services Specification, Fieldbus Foundation*
- *Fieldbus Message Specification, Fieldbus Foundation*

List of Administrative Functions

Table 1-1. List of Administrative Functions

Function	Purpose
nifClose	Close an open descriptor
nifDownloadDomain	Download data to the virtual field device (VFD) domain
nifGetBlockList	Return a list of information for all blocks of the specified type present in the VFD
nifGetDeviceList	Return the list of information for all active devices on the network
nifGetInterfaceList	Read the list of interface names from the NI-FBUS Communications Manager configuration
nifGetVFDList	Gather VFD information on a specified physical device
nifOpenBlock	Return a descriptor representing a block
nifOpenLink	Return a descriptor representing a Fieldbus link
nifOpenPhysicalDevice	Return a descriptor representing a physical device
nifOpenSession	Return a descriptor for an NI-FBUS session
nifOpenVfd	Return a descriptor representing a VFD

nifDownloadDomain

Purpose

Download data from `fileName` to the specified VFD domain according to the `index` value.

Format

```
nifError_t nifDownloadDomain (nifDesc_t ud, uint16 index, char
                             *fileName)
```

Input

<code>ud</code>	The descriptor of the VFD you are accessing by <code>index</code> .
<code>index</code>	The absolute VFD index value of the domain you specified to download the data.
<code>fileName</code>	The name of the file where the download data is stored.

Context

VFD, physical device, link, session.

Description

`nifDownloadDomain` is used to download the data or parameter values to the specified VFD domain. The domain is specified by `index`.

To determine the index value you need, consult the documentation of the device to which you are trying to download the domain. If the device supports the Domain Download feature, the index for download should be specified in the documentation.

Return Values

<code>E_OK</code>	The call was successful.
<code>E_INVALID_DESCRIPTOR</code>	The descriptor you specified is not valid.
<code>E_SERVER_CONNECTION_LOST</code>	The session established with the NI-FBUS Communication Manager, under which the descriptor was opened, has been lost or closed.
<code>E_RESOURCE</code>	The NI-FBUS Communications Manager is unable to allocate some system resource; this is usually a memory problem.
<code>E_DEVICE_CHANGED</code>	The device you specified is changed.
<code>E_VFD_CHANGED</code>	The VFD you specified is changed.

nifGetBlockList

Purpose

Returns a list of information for all blocks of the specified type present in the VFD.

Format

```
nifError_t nifGetBlockList(nifDesc_t ud, uint8 whichTypes,
                          nifBlockInfo_t *info, uint16 *numBlocks)
```

Input

<code>ud</code>	The descriptor of a VFD.
<code>whichTypes</code>	Specifies what types of blocks to return (function, transducer, or physical).
<code>numBlocks</code>	The number of buffers allocated in the <code>info</code> list.

Output

<code>info</code>	The list of information associated with each block.
<code>numBlocks</code>	The number of blocks actually in the VFD.

Context

VFD.

Description

`nifGetBlockList` returns information about all the blocks in the specified VFD. A *block* can be a resource block, transducer block, or function block residing within a VFD. Only blocks of the types specified by `whichTypes` are returned.

To determine how many list items are to be returned in the call, call the function twice. The first time you call the function, set the `numBlocks` parameter to 0. The function will return an error stating that there were not enough buffers configured, and it will return a new number for `numBlocks`. Use this new `numBlocks` parameter to allocate memory for the data. When you call the function the second time, use this new parameter. By doing so, you will allocate only as much memory as necessary.

`nifBlockInfo_t` is defined as follows:

```
typedef struct {
    char          fbTag[TAG_SIZE + 1];
    uint16        startIndex;
    uint32        ddName;
    uint32        ddItem;
```

```

uint16      ddRev;
uint16      profile;
uint16      profileRev;
uint32      executionTime;
uint32      periodExecution;
uint16      numParams;
uint16      nextFb;
uint16      startViewIndex;
uint8       numView3;
uint8       numView4;
uint16      ordNum;
uint8       blockType;
} nifBlockInfo_t;

```

The `blockType` field in `nifBlockInfo_t` can be `FUNCTION_BLOCK`, `TRANSDUCER_BLOCK`, or `RESOURCE_BLOCK`.

The `whichTypes` parameter must be a bit combination of `FUNCTION_BLOCK`, `TRANSDUCER_BLOCK`, and `RESOURCE_BLOCK`.

Return Values

<code>E_OK</code>	The call was successful.
<code>E_INVALID_DESCRIPTOR</code>	The descriptor was invalid or of the wrong type.
<code>E_COMM_ERROR</code>	The NI-FBUS Communications Manager failed to communicate with the device.
<code>E_BUF_TOO_SMALL</code>	The buffer does not contain enough entries to hold all the information for the blocks. If you receive this error, buffer entries that you allocated do not contain valid block information when the call returns.
<code>E_OBSOLETE_DESC</code>	The input descriptor is no longer valid. It was closed before <code>nifGetBlockList</code> completed.
<code>E_BAD_ARGUMENT</code>	The <code>whichTypes</code> value is something other than <code>FUNCTION_BLOCK</code> , <code>TRANSDUCER_BLOCK</code> , or <code>RESOURCE_BLOCK</code> .
<code>E_RESOURCES</code>	A system resource problem occurred. The resource problem is usually a memory shortage.
<code>E_BAD_DEVICE_DATA</code>	The device returned some inconsistent information.
<code>E_SERVER_CONNECTION_LOST</code>	The session established with the NI-FBUS Communications Manager for this descriptor has been closed or lost.

nifGetDeviceList

Purpose

Return the list of information for all active devices on the network.

Format

```
nifError_t nifGetDeviceList(nifDesc_t link,
                             nifDeviceInfo_t *devInfo, uint16 *numDevices,
                             uint16 *revision)
```

Input

<code>link</code>	The link descriptor to return information for.
<code>numDevices</code>	The number of allocated list entries.
<code>revision</code>	The revision number from the last <code>nifGetDeviceList</code> call, or zero (see the <i>Description</i> section for usage).

Output

<code>devInfo</code>	The list of device information.
<code>numDevices</code>	The number of devices present in the link.
<code>revision</code>	Current revision number of the live list that the NI-FBUS Communications Manager reads from the Fieldbus interface to the specified link.

Context

Link.

Description

`nifGetDeviceList` returns a list of information describing each device on the link. A *link* is a group of Fieldbus devices connected across a single wire pair with no intervening bridges. Before `nifGetDeviceList` returns the list of information, `nifGetDeviceList` waits until the revision argument passed in differs from the live list revision number the Fieldbus interface keeps to the specified link. The revision numbers the Fieldbus interface keeps start at one, so if you pass in a zero for `revision`, you can force `nifGetDeviceList` to immediately return the current device list. To use `nifGetDeviceList` most effectively, in subsequent calls to it, you should pass in the `revision` parameter output from the previous call to `nifGetDeviceList`. Using the revision parameter output from the previous call forces `nifGetDeviceList` to wait until the device list has actually changed before returning the list of information.

If a device on the bus is unresponsive, its entry in the device information list has the tag and device ID `unknown device`, but its address field is correct. Also, the flag bit `NIF_DEV_NO_RESPONSE` is set.

The device list includes devices in the fixed, temporary, and visitor address ranges.

If there are too few input buffers, `nifGetDeviceList` returns an error code, but the `numDevices` parameter is set to the total number of devices available. In this case, the buffers you pass in do *not* contain valid data, but the revision number is set to the correct value. If a device is an interface device, then the flag bit `NIF_DEV_INTERFACE` is set. You can abort a pending `nifGetDeviceList` call by closing the link descriptor on which the call was made.

To determine how many list items are to be returned in the call, call the function twice. The first time you call the function, set the `numDevices` parameter to 0. The function will return an error stating that there were not enough buffers configured, and it will return a new number for `numDevices`. Use this new `numDevices` parameter to allocate memory for the data. When you call the function the second time, use this new parameter. By doing so, you will allocate only as much memory as necessary.

`nifDeviceInfo_t` is defined as follows:

```
typedef struct {
    char deviceID[DEV_ID_SIZE + 1];
    char pdTag[TAG_SIZE + 1];
    uint8 nodeAddress;
    uint32 flags;
} nifDeviceInfo_t;
```

Return Values

<code>E_OK</code>	The call was successful.
<code>E_INVALID_DESCRIPTOR</code>	The link descriptor is invalid.
<code>E_BUF_TOO_SMALL</code>	There are not enough buffers allocated. If you receive this error, your input buffers do not contain valid data.
<code>E_COMM_ERROR</code>	The NI-FBUS Communications Manager failed to communicate with the device.
<code>E_OBSOLETE_DESC</code>	The input descriptor is no longer valid. It was closed before <code>nifGetDeviceList</code> completed.
<code>E_SERVER_CONNECTION_LOST</code>	The session established with the NI-FBUS Communications Manager for this descriptor has been closed or lost.

nifGetInterfaceList

Purpose

Read the list of interface names from the NI-FBUS Communications Manager configuration.

Format

```
nifError_t nifGetInterfaceList(nifDesc_t ud,
                               int16 *numIntf, nifInterfaceInfo_t *info)
```

Input

<code>ud</code>	A valid session descriptor.
<code>numIntf</code>	The number of buffers for interface information reserved in <code>info</code> .

Output

<code>numIntf</code>	The actual number of names returned.
<code>info</code>	An array of structures containing the interface name and device ID for each interface.

Context

Not applicable.

Description

`nifGetInterfaceList` returns the interface name and device ID of each Fieldbus interface. The `numIntf` parameter is an IN/OUT parameter. On input, it must contain the number of buffers that `info` allocates and points to, and on output it contains the total number of interface information entries available. If not enough buffers were allocated, or if the `info` buffer is NULL, the NI-FBUS Communications Manager returns an error and does not copy any data to the buffers. In this case, the `numIntf` parameter is still valid.

To determine how many list items are to be returned in the call, call the function twice. The first time you call the function, set the `numIntf` parameter to 0. The function will return an error stating that there were not enough buffers configured, and it will return a new number for `numIntf`. Use this new `numIntf` parameter to allocate memory for the data. When you call the function the second time, use this new parameter. By doing so, you will allocate only as much memory as necessary.

The `nifInterfaceInfo_t` structure is defined as follows:

```
typedef struct nifInterfaceInfo_t{
    char        interfaceName[NIF_NAME_LEN];
    char        deviceID[DEV_ID_SIZE +1];
} nifInterfaceInfo_t;
```



Note `nifGetInterfaceList` is an internal function for the NI-FBUS Communications Manager and does not cause Fieldbus activity.

Return Values

<code>E_OK</code>	The call was successful.
<code>E_BUF_TOO_SMALL</code>	The buffer does not contain enough entries to hold all the interface information.
<code>E_CONFIG_ERROR</code>	Some configuration information, such as registry information or network configuration information, is incorrect.
<code>E_NOT_FOUND</code>	Some interfaces are missing in the bus.

nifGetVFDList

Purpose

Gather VFD information on a specified physical device.

Format

```
nifError_t nifGetVFDList(nifDesc_t ud, nifVFDInfo_t *info,
                        uint16 *numBuffers)
```

Input

<code>ud</code>	The descriptor of the physical device to get the VFD list for.
<code>numBuffers</code>	The number of buffers allocated in the <code>info</code> list.

Output

<code>numBuffers</code>	The number of VFDs actually in the device.
<code>info</code>	The VFD information.

Context

Physical device.

Description

`nifGetVFDList` gathers function block application VFD information from the specified physical device.

If there are too few input buffers, or if the input buffer pointer is `NULL`, an error code is returned, but the `numBuffers` parameter is set to the total number of VFDs in the device. In this case, no buffers contain valid data on output.

To determine how many list items are to be returned in the call, call the function twice. The first time you call the function, set the `numBuffers` parameter to 0. The function will return an error stating that there were not enough buffers configured, and it will return a new number for `numBuffers`. Use this new `numBuffers` parameter to allocate memory for the data. When you call the function the second time, use this new parameter. By doing so, you will allocate only as much memory as necessary.

The `info` parameter has the following format:

```
typedef struct {
    char    vfdTag[TAG_SIZE + 1];
    char    vendor[TAG_SIZE +1];
    char    model [TAG_SIZE +1];
    char    revision[TAG_SIZE +1];
```

```

    int16      ODVersion;
    uint16     numTransducerBlocks;
    uint16     numFunctionBlocks;
    uint16     numActionObjects;
    uint16     numLinkObjects;
    uint16     numAlertObjects;
    uint16     numTrendObjects;
    uint16     numDomainObjects;
    uint16     totalObjects;
    uint32     flags;
} nifVFDInfo_t;

```

Return Values

<code>E_OK</code>	The call was successful.
<code>E_COMM_ERROR</code>	The NI-FBUS Communications Manager failed to communicate with the device.
<code>E_INVALID_DESCRIPTOR</code>	The input descriptor does not correspond to a physical device.
<code>E_BUF_TOO_SMALL</code>	There were not enough allocated buffers. Your specified input buffers do <i>not</i> contain valid data.
<code>E_SM_NOT_OPERATIONAL</code>	The device is present, but cannot respond because it is at a default address.
<code>E_OBSOLETE_DESC</code>	The input descriptor is no longer valid. It was closed before <code>nifGetVFDList</code> completed.
<code>E_SERVER_CONNECTION_LOST</code>	The session established with the NI-FBUS Communications Manager for this descriptor has been closed or lost.
<code>E_BAD_DEVICE_DATA</code>	The device returned some inconsistent information.

nifOpenBlock

Purpose

Return a descriptor representing a block.

Format

```
nifError_t nifOpenBlock (nifDesc_t ud, char *blockTag,
                        nifDesc_t *out_ud)

nifError_t nifOpenBlock (nifDesc_t ud, NIFB_ORDINAL(n),
                        nifDesc_t *out_ud)
```

Input

<code>ud</code>	A valid session, link, physical device, or VFD descriptor.
<code>blockTag</code>	The tag of the block. To access a block by ordinal number within a VFD, use the <code>NIFB_ORDINAL</code> macro in the <code>nifbus.h</code> header file. You can only access a block by ordinal number for VFD descriptors.

Output

<code>out_ud</code>	A descriptor for the block you request.
---------------------	---

Context

VFD, physical device, link, session.

Description

`nifOpenBlock` returns a descriptor for the block you specify. You must pass a valid session, link, physical device, or VFD descriptor to this function.

There are two ways to specify the block: by tag, and by ordinal number. To open the block by its tag, you must set `blockTag` to the current tag of the block. The NI-FBUS Communications Manager returns an error if it finds more than one block with the same tag. You can obtain the list of block tags within a specified VFD with a call to `nifGetBlockList`.

To open the block by its ordinal number, use the `NIFB_ORDINAL` macro. This macro is only valid if `ud` is a VFD descriptor. The first block in a VFD has the ordinal number zero. Notice that the first block in a VFD is always the resource block.

Return Values

<code>E_OK</code>	The call was successful.
<code>E_INVALID_DESCRIPTOR</code>	The input descriptor is invalid.
<code>E_MULTIPLE</code>	There are identical block tags.
<code>E_ORDINAL_NUM_OUT_OF_RANGE</code>	The ordinal number is out of the device's range.
<code>E_COMM_ERROR</code>	An error occurred when the NI-FBUS Communications Manager communicated with the device.
<code>E_NOT_FOUND</code>	There is no such block in the device or VFD with the specified tag.
<code>E_OBSOLETE_DESC</code>	The input descriptor is no longer valid. It was closed before <code>nifOpenBlock</code> completed.
<code>E_RESOURCES</code>	A system resource problem occurred. The resource problem is usually a memory shortage.
<code>E_SERVER_CONNECTION_LOST</code>	The session established with the NI-FBUS Communications Manager for this descriptor has been closed or lost.
<code>E_BAD_DEVICE_DATA</code>	The device returned some inconsistent information.

nifOpenLink

Purpose

Return a descriptor representing a Fieldbus link.

Format

```
nifError_t nifOpenLink (nifDesc_t session, uint8 interfaceOrDevID,
                        char *name, uint16 linkID, nifDesc_t *out_ud)
```

Input

<code>session</code>	A valid session descriptor on which to open the link.
<code>interfaceOrDevID</code>	How to specify the link: zero if by interface name, one if by local device ID.
<code>name</code>	The interface name or local device ID.
<code>linkID</code>	The link ID.

Output

<code>out_ud</code>	A descriptor for the link you request.
---------------------	--

Context

Session.

Description

`nifOpenLink` returns a descriptor for the link you specify. You must pass a valid session descriptor to this function.

There are two ways you can specify the link. If the `interfaceOrDevID` parameter is zero, then `name` specifies the name of the interface the link is connected to. The list of valid interface names is contained in a configuration source which the NI-FBUS Communications Manager has access to, and can be obtained by a call to `nifGetInterfaceList`. If `interfaceOrDevID` is one, then the `name` specifies the device ID of an interface device to which the NI-FBUS Communications Manager is attached.

In both cases, `linkID` is the Fieldbus link ID number for the specified link. For single-link Fieldbus networks, you can set `linkID` to zero.

Return Values

<code>E_OK</code>	The call was successful.
<code>E_INVALID_DESCRIPTOR</code>	The input descriptor is invalid.
<code>E_CONFIG_ERROR</code>	Some configuration information, such as registry information or network configuration information, is incorrect.
<code>E_NOT_FOUND</code>	The interface name, device ID, or link ID you specified is not found.
<code>E_RESOURCES</code>	A system resource problem occurred. The resource problem is usually a memory shortage.
<code>E_BAD_ARGUMENT</code>	The <code>interfaceOrDevID</code> value is not valid.
<code>E_OBSOLETE_DESC</code>	The input descriptor is no longer valid. It was closed before <code>nifOpenLink</code> completed.
<code>E_SERVER_CONNECTION_LOST</code>	The session established with the NI-FBUS Communications Manager for this descriptor has been closed or lost.

nifOpenPhysicalDevice

Purpose

Return a descriptor representing a physical device.

Format

```
nifError_t nifOpenPhysicalDevice (nifDesc_t ud, uint8 tagOrDevID,
                                   char *name, nifDesc_t *out_ud)
```

Input

ud	A valid session or link descriptor on which to open the device.
tagOrDevID	How to specify the device: zero if by physical device tag, one if by device ID.
name	The tag or device ID.

Output

out_ud	A descriptor for the device you request
--------	---

Context

Link, session.

Description

nifOpenPhysicalDevice returns a descriptor for the physical device you specify. You must pass a valid session or link descriptor to this function. If you pass a link descriptor, the NI-FBUS Communications Manager searches only that link for the specified device.

There are two ways you can specify the device. If the *tagOrDevID* parameter is zero, then the *name* specifies the tag of the physical device. If *tagOrDevID* is one, then *name* is the device ID of the device you specify. You can obtain the list of physical device tags and device IDs of devices on the network with a call to *nifGetDeviceList*.

Return Values

E_OK	The call was successful.
E_INVALID_DESCRIPTOR	The input descriptor is invalid.
E_BAD_ARGUMENT	The <i>tagOrDevID</i> value is not valid.
E_NOT_FOUND	No attached physical device has the specified device ID or physical device tag.
E_MULTIPLE	There is more than one device with the same tag or device ID on the same Fieldbus network.

`E_COMM_ERROR`

An error occurred when the NI-FBUS Communications Manager communicated with the device.

`E_RESOURCES`

A system resource problem occurred. The resource problem is usually a memory shortage.

`E_OBSOLETE_DESC`

The input descriptor is no longer valid. It was closed before `nifOpenPhysicalDevice` completed.

`E_SERVER_CONNECTION_LOST`

The session established with the NI-FBUS Communications Manager for this descriptor has been closed or lost.

nifOpenSession

Purpose

Return a descriptor for an NI-FBUS Communications Manager session.

Format

```
nifError_t nifOpenSession (void *reserved, nifDesc_t *out_ud)
```

Input

`reserved` Reserved for future use; you must set this value to NULL.

Output

`out_ud` A descriptor for the NI-FBUS Communications Manager communications entity you request.

Context

Not applicable.

Description

`nifOpenSession` returns a descriptor for the NI-FBUS Communications Manager session. When you open a session, the NI-FBUS Communications Manager establishes a communication channel between your application and the NI-FBUS entity. All subsequent descriptors you open are associated with this session, and all the NI-FBUS calls on these descriptors communicate with the NI-FBUS entity through the communication channel established during the `nifOpenSession` call.

The `reserved` argument is reserved for future use; you must set `reserved` to NULL.

Return Values

<code>E_OK</code>	The call was successful.
<code>E_SERVER_NOT_RESPONDING</code>	Either the NI-FBUS Communications Manager server has not been started, or the server, in its current state, cannot respond to the request.
<code>E_RESOURCES</code>	A system resource problem occurred. The resource problem is usually a memory shortage, or a failure of file access functions.

nifOpenVfd

Purpose

Return a descriptor representing a Virtual Field Device (VFD).

Format

```
nifError_t nifOpenVfd (nifDesc_t ud, char *vfdTag,
                      nifDesc_t *out_ud)
nifError_t nifOpenVfd (nifDesc_t ud, NIFB_ORDINAL(n),
                      nifDesc_t *out_ud)
```

Input

ud	A valid physical device descriptor.
vfdTag	The tag of the VFD. To access by ordinal number within a physical device, use the <code>ORDINAL</code> macro in the <code>nifbus.h</code> header file.

Output

out_ud	A descriptor for the VFD you request.
--------	---------------------------------------

Context

Physical device.

Description

`nifOpenVfd` returns a descriptor for the VFD you specify. More than one VFD can reside within a physical device. You must pass a valid physical device descriptor to this function.

There are two ways to specify the VFD: by tag and by ordinal number. To open the VFD by its tag, you must set the `vfdTag` parameter to the current tag of the VFD. The NI-FBUS Communications Manager returns an error if it finds more than one VFD with the same tag. You can obtain the list of VFD tags within a specified physical device with a call to `nifGetVFDList`.

To open the VFD by its ordinal number, use the `NIFB_ORDINAL` macro. The first VFD of your application in a physical device has the ordinal number zero. Notice that the Management VFDs are not included in the ordinal numbering scheme.

Return Values

<code>E_OK</code>	The call was successful.
<code>E_INVALID_DESCRIPTOR</code>	The input descriptor is invalid.
<code>E_MULTIPLE</code>	There are identical VFD tags.
<code>E_ORDINAL_NUM_OUT_OF_RANGE</code>	The ordinal number is out of the device's range.
<code>E_COMM_ERROR</code>	An error occurred when the NI-FBUS Communications Manager communicated with the device.
<code>E_NOT_FOUND</code>	No VFD in the device has the specified VFD tag.
<code>E_RESOURCES</code>	A system resource problem occurred. The resource problem is usually a memory shortage.
<code>E_SM_NOT_OPERATIONAL</code>	The device is present, but cannot respond because it is at a default address.
<code>E_OBSOLETE_DESC</code>	The input descriptor is no longer valid. It was closed before <i>nifOpenVfd</i> completed.
<code>E_SERVER_CONNECTION_LOST</code>	The session established with the NI-FBUS Communications Manager for this descriptor has been closed or lost.
<code>E_BAD_DEVICE_DATA</code>	The device returned some inconsistent information.

Core Fieldbus Functions

You can use the NI-FBUS core functions to access Fieldbus block parameters using any type of descriptor. Because there are several ways to identify the Fieldbus block parameters, the NI-FBUS core functions accept special interface macros for the `name` argument, as well as the standard `TAG.PARAM` identifier format. Refer to the *Using Interface Macros* section for tips on using the interface macros.

List of Core Functions

Table 2-1. List of Core Functions

Function	Purpose
<code>nifFreeObjectAttributes</code>	Free an <code>nifAttributes_t</code> structure allocated during a previous call to <code>nifGetObjectAttributes</code> .
<code>nifFreeObjectType</code>	Free an <code>nifObjTypeLinst_t</code> structure allocated during a previous call to <code>nifGetObjectType</code> .
<code>nifGetObjectAttributes</code>	Read a single set of object attributes from the Device Description (DD).
<code>nifGetObjectName</code>	Returns the Object Dictionary symbol name of the specified object.
<code>nifGetObjectSize</code>	Return the size in bytes of an object's value.
<code>nifGetObjectType</code>	Returns the Object Dictionary type of the specified object.
<code>nifReadObject</code>	Read an object's value from a device.
<code>nifReadObjectList</code>	Read the values of several objects from a device or several devices.
<code>nifWriteObject</code>	Write a parameter value to a device.

nifFreeObjectAttributes

Purpose

Free an `nifAttributes_t` structure allocated during a previous call to `nifGetObjectAttributes`.

Format

```
nifError_t nifFreeObjectAttributes(nifAttributes_t *attr)
```

Input

`attr` Object attribute values your application reads using `nifGetObjectAttributes`.

Output

Not applicable.

Context

Session, block, VFD, physical device, link.

Description

`nifFreeObjectAttributes` frees up the memory associated with the `nifAttributes_t` structure specified by `attr`. `attr` must have been filled in by a successful call to `nifGetObjectAttributes`. Once this function has been called, the contents of `attr` are no longer valid.

If your application does not call this function after calling `nifGetObjectAttributes`, your application will not free up memory properly.

Return Values

<code>E_OK</code>	The call was successful.
<code>E_BAD_ARGUMENT</code>	<code>attr</code> was not a valid <code>nifAttributes_t</code> structure.

nifFreeObjectType

Purpose

Frees the `nifObjTypeList_t` structure allocated during a previous call to `nifGetObjectType`.

Format

```
nifError_t nifFreeObjectType(nifObjTypeList_t *typeData)
```

Input

<code>typeData</code>	Object Type values to be freed. These values were previously read with the <code>nifGetObjectType</code> function call.
-----------------------	---

Output

Not applicable.

Context

Session, block, VFD, physical device, link.

Description

`nifFreeObjectType` frees up the memory associated with the `nifObjTypeList_t` structure specified by `typeData`. `typeData` must have been filled in by a successful call to `nifGetObjectType`. Once this function has been called, the contents of `typeData` are no longer valid.

If your application does not call this function after calling `nifGetObjectType`, your application will not free up memory properly.

Refer to `nifGetObjectType` to get more details about the `nifObjTypeList_t` structure.

Return Values

<code>E_OK</code>	The call was successful.
<code>E_BAD_ARGUMENT</code>	<code>typeData</code> was not a valid <code>nifObjTypeList_t</code> structure.

nifGetObjectAttributes

Purpose

Read a single set of object attributes from the Device Description (DD).

Format

```
nifError_t nifGetObjectAttributes(nifDesc_t ud, char *name,
                                   nifAttributes_t *attr)

nifError_t nifGetObjectAttributes(nifDesc_t ud,
                                   NIFB_INDEX(uint16 idx), nifAttributes_t *attr)

nifError_t nifGetObjectAttributes(nifDesc_t ud,
                                   NIFB_INDEX_SUBINDEX(uint16 idx, uint16 subidx),
                                   nifAttributes_t *attr)

nifError_t nifGetObjectAttributes(nifDesc_t ud,
                                   NIFB_ITEM(uint32 item), nifAttributes_t *attr)

nifError_t nifGetObjectAttributes(nifDesc_t ud,
                                   NIFB_ITEM_SUBINDEX(uint32 item, uint16 subidx),
                                   nifAttributes_t *attr)

nifError_t nifGetObjectAttributes(nifDesc_t ud,
                                   NIFB_BLOCK_ITEM(char *blocktag, uint32 item),
                                   nifAttributes_t *attr)

nifError_t nifGetObjectAttributes(nifDesc_t ud,
                                   NIFB_BLOCK_ITEM_SUBINDEX(char *blocktag, uint32 item,
                                                             uint16 subidx), nifAttributes_t *attr)

nifError_t nifGetObjectAttributes(nifDesc_t ud,
                                   NIFB_BLOCK_INDEX(char *blocktag, uint16 idx),
                                   nifAttributes_t *attr)

nifError_t nifGetObjectAttributes(nifDesc_t ud,
                                   NIFB_BLOCK_INDEX_SUBINDEX(char *blocktag, uint16 idx,
                                                             uint16 subidx), nifAttributes_t *attr)

nifError_t nifGetObjectAttributes(nifDesc_t ud,
                                   NIFB_NAME_SUBINDEX(char *name, uint16 subidx),
                                   nifAttributes_t *attr)

nifError_t nifGetObjectAttributes(nifDesc_t ud,
                                   NIFB_BLOCK_NAME_SUBINDEX(char *blocktag, char *name,
                                                            uint16 subidx), nifAttributes_t *attr)
```

Input

<code>ud</code>	The descriptor (of any type if by name; VFD or block if by index).
<code>name</code>	Name of the object you need the device description attributes of, in <i>BLOCKTAG.PARAM</i> form. To specify a structure element by name, specify the name in <i>BLOCKTAG.STRUCT.ELEMENT</i> format. Refer to Table 2-4 for an explanation of how to use macros to specify the object.

Output

<code>attr</code>	Object attribute values read from the DDOD (Device Description Object Dictionary). The type <code>nifAttributes_t</code> consists of a data structure including a type code which selects from a list of structures, one for each type of object. Other information, including whether individual attributes were successfully evaluated and whether individual attributes are dynamic (meaning they could change) is also provided. The structure is too long to be included in this manual, so you can find it in the NI-FBUS Communications Manager header files.
-------------------	--

Context

Session, block, VFD, physical device, link.

Description

The NI-FBUS Communications Manager reads the device description object attributes identified in the call from the DDOD associated with `ud` and returned in `attr`. Notice that the object attributes describe certain characteristics of the object, but do not contain the object's value. The device description object attributes also differ in content from the FMS Object Description of the object.

For block, VFD, physical device, or link descriptors, the object name may refer to a variable or a variable list. You would normally use `nifGetObjectAttributes` to read the type description of a certain data type.

Refer to Table 2-4 for an explanation of how to use macros to specify the object.

For more detailed information concerning the `nifAttributes_t` structure, refer to Chapter 3, *Using ddi_get_item*, in the *Fieldbus Foundation Device Description Services User Guide*.



Note After a successful call to `nifGetObjectAttributes`, your application must call `nifFreeObjectAttributes` when it is done using the `attr` structure. Your application will not free up memory correctly if it does not perform this operation.

Return Values

<code>E_OK</code>	The call was successful.
<code>E_CONFIG_ERROR</code>	Some configuration information, such as registry information or network configuration information, is incorrect.
<code>E_INVALID_DESCRIPTOR</code>	The device descriptor does not correspond to a VFD or block.
<code>E_SYMBOL_FILE_NOT_FOUND</code>	The NI-FBUS Communications Manager could not find the symbol file.
<code>E_SM_NOT_OPERATIONAL</code>	The device is present, but cannot respond because it is at a default address.
<code>E_NOT_FOUND</code>	The referred object does not exist, or it does not have object attributes.
<code>E_MULTIPLE</code>	The NI-FBUS Communications Manager found more than one identical tag; the function failed.
<code>E_ORDINAL_NUM_OUT_OF_RANGE</code>	The ordinal number is out of the device's range.
<code>E_OBSOLETE_DESC</code>	The input descriptor is no longer valid. It was closed before <i>nifGetObjectAttributes</i> completed.
<code>E_SERVER_CONNECTION_LOST</code>	The session established with the NI-FBUS Communications Manager for this descriptor has been closed or lost.

nifGetObjectName

Purpose

Returns the Object Dictionary symbol name of the specified object.

Format

```
nifError_t nifGetObjectName(nifDesc_t ud, char *inName, char
                             *outName)

nifError_t nifGetObjectName(nifDesc_t ud, NIFB_INDEX(uint16 idx),
                             char *outName)

nifError_t nifGetObjectName(nifDesc_t ud, NIFB_INDEX_SUBINDEX(uint16
                             idx, uint16 subidx), char *outName)

nifError_t nifGetObjectName(nifDesc_t ud, NIFB_ITEM(uint32 item),
                             char *outName)

nifError_t nifGetObjectName(nifDesc_t ud, NIFB_ITEM_SUBINDEX(uint32
                             item, uint16 subidx), char *outName)

nifError_t nifGetObjectName(nifDesc_t ud, NIFB_BLOCK_INDEX(char
                             *blocktag, uint32 idx), char *outName)

nifError_t nifGetObjectName(nifDesc_t ud,
                             NIFB_BLOCK_INDEX_SUBINDEX(char *blocktag,
                             uint16 idx, uint16 subidx), char *outName)

nifError_t nifGetObjectName(nifDesc_t ud, NIFB_NAME_SUBINDEX(char
                             *name, uint16 subidx), char *outName)

nifError_t nifGetObjectName(nifDesc_t ud, NIFB_BLOCK_NAME_SUBINDEX
                             (char *blocktag, char *name, uint16 subidx),
                             char *outName)
```

Input

ud	The descriptor of the session, link, physical device, VFD or block if you are accessing by name. If you are accessing by index, ud must be a VFD or block.
inName	The name of the parameter you want to read the OD symbol name in <i>BLOCKTAG.PARAM</i> form. Refer to Table 2-4 for an explanation of how to use macros to specify the parameter. To specify a named structure element, supply name in <i>BLOCKTAG.STRUCT.ELEMENT</i> format.

Output

`outName` The Object symbol name read from the Object Dictionary in the device.

Context

Session, block, VFD, DDOD, physical device, link.

Description

`nifGetObjectName` is used to read the Object Dictionary symbol names of objects such as block, VFD, MIB objects, or communication objects from devices.

- If `ud` is the descriptor of a link, then `inName` must be in `BLOCKTAG.PARAM_NAME` format.
- If `ud` is a session descriptor, then all links are searched for the given `BLOCKTAG.PARAM_NAME`. The call fails if identical `BLOCKTAG.PARAM_NAME` tags are found on the bus. Index access is not allowed for session descriptors.
- If `ud` is the descriptor of a general function block application VFD, and you use the `NIFB_INDEX` macro, the index specified is the index of the object in the VFD.
- If `ud` is the descriptor of a function block, name must be in `PARAM_NAME` format.
- If `ud` is the descriptor of a function block, and you use the `NIFB_INDEX` or `NIFB_INDEX_SUBINDEX` macro, the index specified is the relative index of the parameter within the block. Relative indices start at one for the first parameter. Index zero retrieves the object dictionary symbol name of the block itself.
- In all cases, you can expand `PARAM_NAME` to `STRUCT.ELEMENT` format to represent a named element of a named structure.

Refer to Table 2-4 for an explanation of how to use macros to specify the parameter.

Return Values

<code>E_OK</code>	The call was successful.
<code>E_INVALID_DESCRIPTOR</code>	The descriptor you specified is not valid.
<code>E_NOT_FOUND</code>	The NI-FBUS Communication Manager could not find the specified object.
<code>E_SYMBOL_FILE_NOT_FOUND</code>	The NI-FBUS Communication Manager could not find the symbol file.
<code>E_BAD_ARGUMENT</code>	The object specified by index was that of a simple data type, which must already be known to you.
<code>E_SERVER_CONNECTION_LOST</code>	The session established with the NI-FBUS Communication Manager, under which the descriptor was opened, has been lost or closed.

`E_DEVICE_CHANGED`

The device you specified is changed.

`E_VFD_CHANGED`

The VFD you specified is changed.

`E_COMM_ERROR`

An error occurred when the NI-FBUS Communication Manager tried to communicate with the device.

`E_RESOURCE`

The NI-FBUS Communications Manager is unable to allocate some system resource; this is usually a memory problem.

`E_OBSOLETE_BLOCK`

The block you specified is no longer valid.

nifGetObjectSize

Purpose

Return the size (in bytes) of an object's value.

Format

```
nifError_t nifGetObjectSize(nifDesc_t ud, char *name,
                             int16 *size_in_bytes)
nifError_t nifGetObjectSize(nifDesc_t ud, NIFB_INDEX(uint16 idx),
                             int16 *size_in_bytes)
nifError_t nifGetObjectSize(nifDesc_t ud,
                             NIFB_INDEX_SUBINDEX(uint16 idx, uint16 subidx),
                             int16 *size_in_bytes)
nifError_t nifGetObjectSize(nifDesc_t ud,
                             NIFB_ITEM(uint32 item), int16 *size_in_bytes)
nifError_t nifGetObjectSize(nifDesc_t ud,
                             NIFB_ITEM_SUBINDEX(uint32 item, uint16 subidx),
                             int16 *size_in_bytes)
nifError_t nifGetObjectSize(nifDesc_t ud,
                             NIFB_BLOCK_ITEM(char *blocktag, uint32 item),
                             int16 *size_in_bytes)
nifError_t nifGetObjectSize(nifDesc_t ud,
                             NIFB_BLOCK_ITEM_SUBINDEX(char *blocktag, uint32 item,
                                                         uint16 subidx), int16 *size_in_bytes)
nifError_t nifGetObjectSize(nifDesc_t ud,
                             NIFB_BLOCK_INDEX(char *blocktag, uint16 idx),
                             int16 *size_in_bytes)
nifError_t nifGetObjectSize(nifDesc_t ud,
                             NIFB_BLOCK_INDEX_SUBINDEX(char *blocktag, uint16 idx,
                                                         uint16 subidx), int16 *size_in_bytes)
nifError_t nifGetObjectSize(nifDesc_t ud,
                             NIFB_NAME_SUBINDEX(char *name, uint16 subidx),
                             int16 *size_in_bytes)
nifError_t nifGetObjectSize(nifDesc_t ud,
                             NIFB_BLOCK_NAME_SUBINDEX(char *blocktag, char *name,
                                                         uint16 subidx), int16 *size_in_bytes)
```

Input

<code>ud</code>	The descriptor of a block.
<code>name</code>	Character string name of the object you need the size of, in <i>BLOCKTAG.PARAM</i> form. To specify a structure element by name, specify the name in <i>BLOCKTAG.STRUCT.ELEMENT</i> format. Refer to Table 2-4 for an explanation of how to use macros to specify the character string name.

Output

<code>size_in_bytes</code>	The size of the object.
----------------------------	-------------------------

Context

Session, block, VFD, physical device, link.

Description

This function returns the size of the specified Object Value. You have to pass a buffer of the returned size to `nifReadObject` to hold the value of the object.

Refer to Table 2-4 for an explanation of how to use macros to specify the character string name.

Return Values

<code>E_OK</code>	The call was successful.
<code>E_INVALID_DESCRIPTOR</code>	The specified descriptor is invalid.
<code>E_SYMBOL_FILE_NOT_FOUND</code>	The NI-FBUS Communications Manager could not find the symbol file.
<code>E_NOT_FOUND</code>	The named object does not exist.
<code>E_MULTIPLE</code>	Multiple identical tags were found; the function failed.
<code>E_OBSOLETE_DESC</code>	The input descriptor is no longer valid. It was closed before <code>nifGetObjectSize</code> completed.
<code>E_ORDINAL_NUM_OUT_OF_RANGE</code>	The ordinal number is out of the device's range.
<code>E_SERVER_CONNECTION_LOST</code>	The session established with the NI-FBUS Communications Manager for this descriptor has been closed or lost.

nifGetObjectType

Purpose

Returns the Object Dictionary type of the specified object.

Format

```
nifError_t nifGetObjectType(nifDesc_t ud, char *objName,
                             nifObjTypeList_t *typeData)

nifError_t nifGetObjectType(nifDesc_t ud,
                             NIFB_INDEX(uint16 idx), nifObjTypeList_t *typeData)

nifError_t nifGetObjectType(nifDesc_t ud,
                             NIFB_INDEX_SUBINDEX(uint16 idx, uint16 subidx),
                             nifObjTypeList_t *typeData)

nifError_t nifGetObjectType(nifDesc_t ud,
                             NIFB_ITEM(uint32 item), nifObjTypeList_t *typeData)

nifError_t nifGetObjectType(nifDesc_t ud,
                             NIFB_ITEM_SUBINDEX(uint32 item, uint16 subidx),
                             nifObjTypeList_t *typeData)

nifError_t nifGetObjectType(nifDesc_t ud,
                             NIFB_BLOCK_ITEM(char *blocktag, uint32 item),
                             nifObjTypeList_t *typeData)

nifError_t nifGetObjectType(nifDesc_t ud,
                             NIFB_BLOCK_ITEM_SUBINDEX(char *blocktag, uint32 item,
                                                         uint16 subidx), nifObjTypeList_t *typeData)

nifError_t nifGetObjectType(nifDesc_t ud,
                             NIFB_BLOCK_INDEX(char *blocktag, uint16 idx),
                             nifObjTypeList_t *typeData)

nifError_t nifGetObjectType(nifDesc_t ud,
                             NIFB_BLOCK_INDEX_SUBINDEX(char *blocktag, uint16 idx,
                                                         uint16 subidx), nifObjTypeList_t *typeData)

nifError_t nifGetObjectType(nifDesc_t ud,
                             NIFB_NAME_SUBINDEX(char *name, uint16 subidx),
                             nifObjTypeList_t *typeData)

nifError_t nifGetObjectType(nifDesc_t ud,
                             NIFB_BLOCK_NAME_SUBINDEX(char *blocktag, char *name,
                                                         uint16 subidx), nifObjTypeList_t *typeData)
```

Input

<code>ud</code>	The descriptor of the session, link, physical device, VFD or block if you are accessing by name. If you are accessing by index, <code>ud</code> must be a VFD or block.
<code>objName</code>	The name of the parameter you want to read the OD type of, in <i>BLOCKTAG.PARAM</i> form. Refer to Table 2-4 for an explanation of how to use macros to specify the parameter. To specify a named structure element, supply <code>name</code> in <i>BLOCKTAG.STRUCT.ELEMENT</i> format. To specify a type index returned by a previous call to <i>nifGetObjectType</i> , use the <code>NIFB_TYPE_INDEX</code> macro.

Output

<code>typeData</code>	Object Type value read from the object dictionary in the device. The <code>nifObjTypeList_t</code> data structure is a record consisting of an object type code, the number of elements, the <code>blocktag</code> to which this object belongs (if applicable), and a pointer to a list of elements of type <code>nifObjElem_t</code> . The <code>nifObjElem_t</code> type is a structure which consists of two elements: the OD <code>typeIndex</code> of the element, and the OD length of the element.
-----------------------	--

Context

Session, block, VFD, DDOD, physical device, link.

Description

nifGetObjectType is used to read the Object Dictionary type values of objects such as block parameters, MIB objects, or communication parameters from devices.

- If `ud` is the descriptor of a link, then `objName` must be in *BLOCKTAG.PARAM_NAME* format.
- If `ud` is a session descriptor, then all links are searched for the given *BLOCKTAG.PARAM_NAME*. The call fails if identical *BLOCKTAG.PARAM_NAME* tags are found on the bus. Index access is not allowed for session descriptors.
- If `ud` is the descriptor of a general function block application VFD, and you use the `NIFB_INDEX` macro, the index specified is the index of the object in the VFD.
- If `ud` is the descriptor of a function block, `name` must be in *PARAM_NAME* format.
- If `ud` is the descriptor of a function block, and you use the `NIFB_INDEX` or `NIFB_INDEX_SUBINDEX` macro, the index specified is the relative index of the parameter within the block. Relative indices start at one for the first parameter. Index zero retrieves the OD type of the block itself.
- In all cases, you can expand *PARAM_NAME* to *STRUCT.ELEMENT* format to represent a named element of a named structure.

Refer to Table 2-4 for an explanation of how to use macros to specify the parameter.

The `nifObjTypeList_t` data structure is defined as follows:

```
typedef struct {
    uint8      objectCode;
    uint16     numElems;
    char       blockTag[TAG_SIZE + 1];
    nifObjElem_t *allElems;
} nifObjTypeList_t;
```

The `nifObjElem_t` data type is defined as follows:

```
typedef struct {
    uint16     objTypeIndex;
    uint16     objSize;
} nifObjElem_t;
```

The `objectCode` returned in the data structure `nifObjTypeList_t` is as specified in the *FMS Specifications* section in the *Fieldbus Foundation Specifications* document, and is listed in Table 2-2 for your convenience.

Table 2-2. Object Codes for the `nifObjTypeList_t` Data Structure

Object	Object Code in <code>fbtypes.h</code>
Domain	ODT_DOMAIN
Program Invocation	ODT_PI
Event	ODT_EVENT
Data Type	ODT_SIMPLETYPE
Data Type Structure Description	ODT_STRUCTTYPE
Simple Variable	ODT_SIMPLEVAR
Array	ODT_ARRAY
Record	ODT_RECORD
Variable List	ODT_VARLIST

For object codes `ODT_STRUCTTYPE`, `ODT_SIMPLEVAR`, `ODT_ARRAY`, and `ODT_RECORD`, the list of elements in `allElements` contains the `typeIndex` and the size of each component element. For example, the following fragment of pseudocode gets the type information for a structured object and does something with the type information for each element:

```
nifObjTypeList_t typeInfo;
nifDesc_t aiBlock;
```

```

int loop;
...
nifGetObjectType(aiBlock, "OUT", &typeInfo);
for (loop=0; loop < typeInfo.numElems; loop++)
{
    doSomethingWithElement (typeInfo.allElems [loop]);
}

```

For variable list objects (type `ODT_VARLIST`), you must call `nifGetObjectType` for each element in the list of elements with the `typeIndex` of the element returned in the list with the first `nifGetObjectType` call. The `typeIndex` of the element returned in the list in this case is the relative index of the element within the block, whose name is returned by `blockTag`. These subsequent calls to `nifGetObjectType` should use the `NIFB_INDEX` macro to specify the `typeIndex` returned by the first call.

For example, the following fragment of pseudocode gets the type information for a variable list object and does something with the type information for each variable:

```

nifObjTypeList_t typeInfo, varTypeInfo;
nifDesc_t aiBlock;
int loop;
...
nifGetObjectType(aiBlock, "VIEW_1", &typeInfo);
if (typeInfo.objectCode == ODT_VARLIST)
{
    for (loop=0; loop < typeInfo.numElems; loop++)
    {
        nifGetObjectType(aiBlock,
            NIFB_INDEX(typeInfo.allElems [loop].objTypeIndex),
            &varTypeInfo);
        doSomethingWithVariable (varTypeInfo);
    }
}

```

For all successful calls to `nifGetObjectType`, you must call `nifFreeObjectType` to clean up memory allocated within these structures.

For objects with the object codes ODT_DOMAIN, ODT_PI, ODT_EVENT, and ODT_SIMPLETYPE, only the object type is returned, and the list of elements `allElems` in the structure `nifObjTypeList_t` is empty. The list of standard data types for an object which has the object code ODT_SIMPLETYPE is also as specified in the *FMS Specifications* section in the *Fieldbus Foundation Specifications* document and is listed in Table 2-3 for your convenience.

Table 2-3. Object Codes for the `nifObjTypeList_t` Data Structure

Data Type	objTypeIndex in fbtypes.h	Number of Octets (Size)
Boolean	FF_BOOLEAN	1
Integer8	FF_INTEGER8	1
Integer16	FF_INTEGER16	2
Integer32	FF_INTEGER32	4
Unsigned8	FF_UNSIGNED8	1
Unsigned16	FF_UNSIGNED16	2
Unsigned32	FF_UNSIGNED32	4
Floating Point	FF_FLOAT	4
Visible String	FF_VISIBLE_STRING	1, 2, 3, ...
Octet String	FF_OCTET_STRING	1, 2, 3, ...
Date	FF_DATE	7
Time of Day	FF_TIMEOFDAY	4 or 6
Time Difference	FF_TIME_DIFF	4 or 6
Bit String	FF_BIT_STRING	1, 2, 3, ...
Time Value	FF_TIME_VALUE	8

Return Values

<code>E_OK</code>	The call was successful.
<code>E_INVALID_DESCRIPTOR</code>	The descriptor you specified is not valid.
<code>E_TIMEOUT</code>	The device containing the object is present but did not respond within the timeout period.
<code>E_MULTIPLE</code>	More than one identical tag was found; the function failed.

<code>E_NOT_FOUND</code>	The NI-FBUS Communications Manager could not find the specified object.
<code>E_BAD_ARGUMENT</code>	The object specified by index was that of a simple data type, which must already be known to you.
<code>E_RESOURCES</code>	The NI-FBUS Communications Manager is unable to allocate some system resource; this is usually a memory problem.
<code>E_SERVER_CONNECTION_LOST</code>	The session established with the NI-FBUS Communications Manager, under which the descriptor was opened, has been lost or closed.

nifReadObject

Purpose

Read an object's value from a device.

Format

```
nifError_t nifReadObject(nifDesc_t ud, char *name, void *buffer,
                        uint8 *length)
nifError_t nifReadObject(nifDesc_t ud, NIFB_INDEX(uint16 idx),
                        void *buffer, uint8 *length)
nifError_t nifReadObject(nifDesc_t ud,
                        NIFB_INDEX_SUBINDEX(uint16 idx, uint16 subidx),
                        void *buffer, uint8 *length)
nifError_t nifReadObject(nifDesc_t ud,
                        NIFB_ITEM(uint32 item), void *buffer, uint8 *length)
nifError_t nifReadObject(nifDesc_t ud,
                        NIFB_ITEM_SUBINDEX(uint32 item, uint16 subidx),
                        void *buffer, uint8 *length)
nifError_t nifReadObject(nifDesc_t ud,
                        NIFB_BLOCK_ITEM(char *blocktag, uint32 item),
                        void *buffer, uint8 *length)
nifError_t nifReadObject(nifDesc_t ud,
                        NIFB_BLOCK_ITEM_SUBINDEX(char *blocktag, uint32 item,
                        uint16 subidx), void *buffer, uint8 *length)
nifError_t nifReadObject(nifDesc_t ud,
                        NIFB_BLOCK_INDEX(char *blocktag, uint16 idx),
                        void *buffer, uint8 *length)
nifError_t nifReadObject(nifDesc_t ud,
                        NIFB_BLOCK_INDEX_SUBINDEX(char *blocktag, uint16 idx,
                        uint16 subidx), void *buffer, uint8 *length)
nifError_t nifReadObject(nifDesc_t ud,
                        NIFB_NAME_SUBINDEX(char *name, uint16 subidx),
                        void *buffer, uint8 *length)
nifError_t nifReadObject(nifDesc_t ud,
                        NIFB_BLOCK_NAME_SUBINDEX(char *blocktag, char *name,
                        uint16 subidx), void *buffer, uint8 *length)
```

Input

<code>ud</code>	The descriptor of the session, link, physical device, VFD or block if reading by name. If reading by index, <code>ud</code> must be a VFD or block.
<code>name</code>	Name of the parameter your application reads, in <code>BLOCKTAG.PARAM</code> format. To specify a structure element by name, specify the name in <code>BLOCKTAG.STRUCT.ELEMENT</code> format. Refer to Table 2-4 for an explanation of how to use macros to specify the parameter.
<code>length</code>	The size of the buffer to hold the result, in bytes.

Output

<code>buffer</code>	The value that the NI-FBUS Communications Manager reads.
<code>length</code>	The actual size of the resulting data, in bytes.

Context

Session, block, VFD, physical device, link.

Description

`nifReadObject` reads the values of objects such as block parameters or communications parameters from devices.

- If `ud` is the descriptor of a link, then `name` must be in the format `BLOCKTAG.PARAM_NAME`.
- If `ud` is a session descriptor, then all links are searched for the given `BLOCKTAG.PARAM_NAME`. The call fails if multiple identical `BLOCKTAG.PARAM_NAME` tags are located on the bus. Index access is not allowed for session descriptors.
- If `ud` is the descriptor of a general function block application VFD, then `name` must be in the format `BLOCKTAG.PARAM_NAME`.
- If `ud` is the descriptor of a function block, `name` must be in the format `PARAM_NAME`.
- If `ud` is the descriptor of a function block, and the `NIFB_INDEX` or `NIFB_INDEX_SUBINDEX` macro is used, the index specified is the relative index of the parameter within the block. Relative indices start at 1 for the first parameter.
- In all descriptor cases, you can expand `PARAM_NAME` itself to `STRUCT.ELEMENT` format to represent a named element of a named structure.

In each case, `name` can represent either a variable or a variable list object. You should determine the size of the object beforehand, possibly with a call to `nifGetObjectSize`. If the object is larger than the buffer size specified in `length`, the NI-FBUS Communications Manager returns an error, and none of the data in the buffer is valid.

Refer to Table 2-4 for an explanation of how to use macros to specify the parameter.

The data `nifReadObject` returns is in Fieldbus Foundation FMS Application format. You must accomplish conversion of the data to the internal format of your processor and compiler.

Return Values

<code>E_OK</code>	The call was successful.
<code>E_INVALID_DESCRIPTOR</code>	The descriptor does not correspond to a VFD or function block; this descriptor is no longer valid.
<code>E_NOT_FOUND</code>	The referred object does not exist.
<code>E_OBJECT_ACCESS_DENIED</code>	The NI-FBUS Communications Manager interface does not have the required privileges. The access group you belong to is not allowed to acknowledge the event, or the password you used is wrong.
<code>E_MULTIPLE</code>	The NI-FBUS Communications Manager found more than one identical tag; the function failed.
<code>E_BUF_TOO_SMALL</code>	The object is larger than your buffer.
<code>E_SM_NOT_OPERATIONAL</code>	The device is present, but cannot respond because it is at a default address.
<code>E_SYMBOL_FILE_NOT_FOUND</code>	The NI-FBUS Communications Manager could not find the symbol file.
<code>E_OBSOLETE_DESC</code>	The input descriptor is no longer valid. It was closed before <code>nifReadObject</code> completed.
<code>E_COMM_ERROR</code>	The NI-FBUS Communications Manager failed to communicate with the device.
<code>E_PARAMETER_CHECK</code>	The device reported a violation of parameter-specific checks.
<code>E_SERVER_CONNECTION_LOST</code>	The session established with the NI-FBUS Communications Manager for this descriptor has been closed or lost.

nifReadObjectList

Purpose

Read the values of several objects from a device or several devices.

Format

```
nifError_t nifReadObjectList (nifDesc_t ud, char **blkParamList,
                              uint16 numObjects, void *buffer, uint16 *length,
                              nifError_t *errArray)
```

Input

<code>ud</code>	The descriptor of the session, link, physical device, VFD, or block.
<code>blkParamList</code>	The list of parameter names your application reads in the form of <i>BLOCKTAG.PARAM</i> . To specify any parameter by index use the <i>NIFB_INDEX</i> macro. To specify any parameter that is an array or structure element by index and subindex, use the <i>NIFB_INDEX_SUBINDEX</i> macro. To specify a named structure element, supply the parameter name in the form of <i>BLOCKTAG.STRUCT.ELEMENT</i> .
<code>numObjects</code>	The number of parameter names specified in <code>blkParamList</code> . (The maximum number of objects that can be specified in <code>blkParamList</code> is given by the constant <i>MAX_LIST_ELEMS</i> .)
<code>length</code>	The size of the buffer to hold the result of all the parameter reads, in bytes.

Output

<code>buffer</code>	The values of all the parameters read, stored as a continuous string of bytes.
<code>length</code>	The cumulative size of the actual resulting data in bytes.
<code>errArray</code>	The error codes resulting from each parameter read. The error codes have a one-to-one correspondence with the order in which the parameters are specified in <code>blkParamList</code> .

Context

Session, link, device, VFD, block.

Description

`nifReadObjectList` reads the values of objects specified in the list, which may include block parameters or communication parameters from devices.

- If `ud` is the descriptor of a link, each name in `blkParamList` must be in the format `BLOCKTAG.PARAM_NAME`.
- If `ud` is a session descriptor, then all links are searched for any given name specified by the `blocktag.param` format in `blkParamList`. The read of this particular object fails if identical `BLOCKTAG.PARAM_NAME` tags are located on the bus. Index access is not allowed for session descriptors.
- If `ud` is the descriptor of a general function block application VFD, any name in `blkParamList` must be in the format `blocktag.param_name`.
- If `ud` is the descriptor of a function block, any name in `blkParamList` must be in the format `PARAM_NAME`.
- If `ud` is the descriptor of a function block and the `NIFB_INDEX` or `NIFB_INDEX_SUBINDEX` macro is used to specify a name in `blkParamList`, the index specified is the relative index of the parameter within the block. Relative indices start at 1 for the first block parameter.
- In all descriptor cases, any `PARAM_NAME` specified in `blkParamList` can be expanded to `STRUCT.ELEMENT` format to represent a named element of a named structure.

For each name specified in `blkParamList`, the name can either represent a variable or a variable list object. You should determine the size of each object specified in `blkParamList` beforehand, possibly with a call to `nifGetObjectSize`. If the cumulative size of all the objects specified in the list is larger than the buffer size specified in `length`, the NI-FBUS Communications Manager returns an error. The data in the buffer is valid for however many objects were successfully read. The success or failure of the read for every object specified in `blkParamList` is indicated in `errArray`, the array in which error codes are returned. The error code in the first element of `errArray` is the error code indicating success or failure upon read of the first object specified in `blkParamList`, and so on.

Refer to Table 2-4 for an explanation of how to use macros to specify the parameters in `blkParamList`.

The data `nifReadObjectList` returns is in Fieldbus Foundation FMS Application format. You must accomplish conversion of the data to the internal format of your processor and compiler.

Return Values

`E_OK`

The call was successful.

`E_INVALID_DESCRIPTOR`

The descriptor is no longer valid.

`E_BUF_TOO_SMALL`

The size of the data resulting from the read of all objects specified in the list is larger than your buffer.

`E_RESOURCES`

A system resource problem occurred. The resource problem is usually a memory shortage.

`E_SERVER_CONNECTION_LOST`

The session established with the NI-FBUS Communications Manager for this descriptor has been closed or lost.

nifWriteObject

Purpose

Write a parameter value to a device.

Format

```
nifError_t nifWriteObject(nifDesc_t ud, char *name, void *buffer,
                          uint8 length)
nifError_t nifWriteObject(nifDesc_t ud, NIFB_INDEX(uint16 idx),
                          void *buffer, uint8 length)
nifError_t nifWriteObject(nifDesc_t ud,
                          NIFB_INDEX_SUBINDEX(uint16 idx, uint16 subidx),
                          void *buffer, uint8 length)
nifError_t nifWriteObject(nifDesc_t ud,
                          NIFB_ITEM(uint32 item), void *buffer, uint8 length)
nifError_t nifWriteObject(nifDesc_t ud,
                          NIFB_ITEM_SUBINDEX(uint32 item, uint16 subidx),
                          void *buffer, uint8 length)
nifError_t nifWriteObject(nifDesc_t ud,
                          NIFB_BLOCK_ITEM(char *blocktag, uint32 item),
                          void *buffer, uint8 length)
nifError_t nifWriteObject(nifDesc_t ud,
                          NIFB_BLOCK_ITEM_SUBINDEX(char *blocktag, uint32 item,
                                                      uint16 subidx), void *buffer, uint8 length)
nifError_t nifWriteObject(nifDesc_t ud,
                          NIFB_BLOCK_INDEX(char *blocktag, uint16 idx),
                          void *buffer, uint8 length)
nifError_t nifWriteObject(nifDesc_t ud,
                          NIFB_BLOCK_INDEX_SUBINDEX(char *blocktag, uint16 idx,
                                                      uint16 subidx), void *buffer, uint8 length)
nifError_t nifWriteObject(nifDesc_t ud,
                          NIFB_NAME_SUBINDEX(char *name, uint16 subidx),
                          void *buffer, uint8 length)
nifError_t nifWriteObject(nifDesc_t ud,
                          NIFB_BLOCK_NAME_SUBINDEX(char *blocktag, char *name,
                                                      uint16 subidx), void *buffer, uint8 length)
```

Input

<code>ud</code>	The descriptor of the session, link, physical device, VFD, or block, if writing by name. If writing by index, <code>ud</code> must be a VFD or block.
<code>name</code>	Name of the parameter you want the NI-FBUS Communications Manager to write, in <code>BLOCKTAG.PARAM</code> form. To specify a structure element by name, specify the name in <code>BLOCKTAG.STRUCT.ELEMENT</code> format. Refer to Table 2-4 for an explanation of how to use macros to specify the parameter.
<code>buffer</code>	The value you want the NI-FBUS Communications Manager to write.
<code>length</code>	The size of the data buffer, in bytes.

Output

Not applicable.

Context

Block, VFD, physical device, link, session.

Description

`nifWriteObject` writes the values of a function block parameter to a device.

- If `ud` is the descriptor of a session or link, then `name` must be in the format `BLOCKTAG.PARAM_NAME`.
- If `ud` is a session descriptor, then all links are searched for the given `BLOCKTAG.PARAM_NAME`. The function fails if more than one identical `BLOCKTAG.PARAM_NAME` match is found.
- If `ud` is a physical device descriptor, a parameter is written by `BLOCKTAG.PARAM_NAME`.
- If `ud` is the descriptor of a general Virtual Field Device, then `name` must be in the format `BLOCKTAG.PARAM_NAME`.
- If `ud` is the descriptor of a function block, `name` must be in the format `PARAM_NAME`.
- If `ud` is the descriptor of a function block, and you use the `NIFB_INDEX` or `NIFB_INDEX_SUBINDEX` macro, the index specified is the relative index of the parameter within the block. Relative indices start at one for the first parameter.
- In all descriptor cases, you can expand `PARAM_NAME` itself to `STRUCT.ELEMENT` format to represent a named element of a named structure.

Refer to Table 2-4 for an explanation of how to use macros to specify the parameter.

Return Values

<code>E_OK</code>	The call was successful.
<code>E_INVALID_DESCRIPTOR</code>	The device descriptor does not correspond to a VFD.
<code>E_SYMBOL_FILE_NOT_FOUND</code>	The NI-FBUS Communications Manager could not find the symbol file.
<code>E_ORDINAL_NUM_OUT_OF_RANGE</code>	The parameter is out of the device's range.
<code>E_OBJECT_ACCESS_UNSUPPORTED</code>	The device does not support write access to this object.
<code>E_MULTIPLE</code>	The NI-FBUS Communications Manager found more than one identical tag; the function failed.
<code>E_SM_NOT_OPERATIONAL</code>	The device is present, but cannot respond because it is at a default address.
<code>E_COMM_ERROR</code>	The NI-FBUS Communications Manager failed to communicate with the device.
<code>E_PARAMETER_CHECK</code>	The device reported a violation of parameter-specific checks.
<code>E_EXCEED_LIMIT</code>	The device reported that the value exceeds the limit.
<code>E_WRONG_MODE_FOR_REQUEST</code>	The device reported that the current function block mode does not allow you to write to the parameter.
<code>E_WRITE_IS_PROHIBITED</code>	The device reported that the <code>WRITE_LOCK</code> parameter value is set. The <code>WRITE_LOCK</code> parameter prohibits writing to the name parameter.
<code>E_DATA_NEVER_WRITABLE</code>	The specified object is read-only.
<code>E_SERVER_CONNECTION_LOST</code>	The session established with the NI-FBUS Communications Manager for this descriptor has been closed or lost.

Using Interface Macros

This section contains tips for using the NI-FBUS Communications Manager interface macros. These macros are defined in the header file `nifbus.h`.

Table 2-4. Core Function Macros

Descriptor Type You Have	Parameter Information You Have	Macro to Use
Block Descriptor	Name	Normal Access by Name
	Name and Subindex	<code>NIFB_NAME_SUBINDEX</code>
	Relative Index within the Block	<code>NIFB_INDEX</code>
	Relative Index and Subindex	<code>NIFB_INDEX_SUBINDEX</code>
	Device Description Item ID	<code>NIFB_ITEM</code>
	Device Description Item ID and Subindex	<code>NIFB_ITEM_SUBINDEX</code>
Non-Block Descriptor	Name	Normal Access Using <code>BLOCKTAG.PARAM</code> Format
	Name and Subindex	<code>NIFB_BLOCK_NAME_SUBINDEX</code>
	Relative Index within the Block	<code>NIFB_BLOCK_INDEX</code>
	Relative Index and Subindex	<code>NIFB_BLOCK_INDEX_SUBINDEX</code>
	Device Description Item ID	<code>NIFB_BLOCK_ITEM</code>
	Device Description Item ID and Subindex	<code>NIFB_BLOCK_ITEM_SUBINDEX</code>

As shown in Table 2-4, you can specify the parameter your application reads in the `name` parameter in the following ways:

- To specify an object by index, use the `NIFB_INDEX` macro in the `nifbus.h` header file.
- To specify an array or structure element by index and subindex, use the `NIFB_INDEX_SUBINDEX` macro.
- If you already have a block descriptor, you can specify an object by its item ID with the `NIFB_ITEM` macro, or you can specify a subelement by its item ID with the `NIFB_ITEM_SUBINDEX` macro.

- If you do not have a block descriptor, you have the following choices:
 - You can use the `NIFB_BLOCK_ITEM` macro to specify an item.
 - You can use the `NIFB_BLOCK_ITEM_SUBINDEX` macro to specify a subelement.
 - You can use the `NIFB_BLOCK_INDEX` macro specify an object by index.
 - You can use the `NIFB_BLOCK_INDEX_SUBINDEX` macro to specify a subindex.

You can find all these macros in the `nifbus.h` header file.

Alert and Trend Functions

The following tables list the alert and trend functions.

Table 3-1. Alert Functions

Function	Purpose
nifAcknowledgeAlarm	Acknowledge an alarm received
nifWaitAlert	Wait for an alert (an event or an alarm) from a specific device or from <i>any</i> device

Table 3-2. Trend Function

Function	Purpose
nifWaitTrend	Wait for a trend from a specific device or from any device

nifAcknowledgeAlarm

Purpose

Acknowledge an alarm received.

Format

```
nifError_t nifAcknowledgeAlarm(nifDesc_t ud, char *alarmName)
```

Input

ud	A session, link, physical device, VFD, or block descriptor for the alarm.
alarmName	The name of the alarm object that you want the NI-FBUS Communications Manager to acknowledge. If ud is a block descriptor, alarmName should be the parameter name, otherwise alarmName should be in <i>BLOCKTAG.PARAMNAME</i> format.

Context

Block, VFD, physical device, link, session.

Description

nifAcknowledgeAlarm acknowledges an alarm notification from a device. The NI-FBUS Communications Manager clears the *unacknowledged* field associated with the alarm object *alarmName*.

If *ud* is a block descriptor, the *alarmName* is the same as the *alarmOrEventName* field of the alert data you get in the *nifWaitAlert* call. If *ud* is a session, link, VFD, or physical device descriptor, then *alarmName* is in *BLOCKTAG.PARAMNAME* format, where *blockTag* is the same as the *blockTag* field of the alert data in the *nifWaitAlert* function.

Return Values

E_OK	The call was successful.
E_INVALID_DESCRIPTOR	The device descriptor is not a valid descriptor.
E_OBJECT_ACCESS_DENIED	The NI-FBUS Communications Manager interface does not have the required privileges. The access group you belong to is not allowed to acknowledge the event, or the password you used is wrong.
E_COMM_ERROR	An error occurred when the NI-FBUS Communications Manager tried to communicate with the device.
E_ALARM_ACKNOWLEDGED	The alarm has already been acknowledged.

E_MULTIPLE

There are identical block tags.

E_NOT_FOUND

There is no such block in the device or VFD with the specified tag.

E_SYMBOL_FILE_NOT_FOUND

The NI-FBUS Communications Manager could not find the symbol file.

E_SERVER_CONNECTION_LOST

The session established with the NI-FBUS Communications Manager for this descriptor has been closed or lost.

nifWaitAlert

Purpose

Wait for an alert (an event or an alarm) from a specific device or from *any* device.

Format

```
nifError_t nifWaitAlert(nifDesc_t ud, nifAlertData_t *aldata,
                        uint8 alertPriority)
```

Input

<code>ud</code>	The descriptor of the session, link, physical device, VFD, block, or link the alert comes from.
<code>alertPriority</code>	Lowest priority of the alert coming in that you want to wait on.

Output

<code>aldata</code>	The information about the specific alert.
---------------------	---

Context

Block, VFD, physical device, link, session.

Description

`ud` represents a descriptor of a session, link, a physical device, a VFD, or a block. If `ud` is a VFD descriptor, then the NI-FBUS Communications Manager waits for an alert from any block in the Virtual Field Device. If `ud` is a block, the NI-FBUS Communications Manager waits for an alarm or event from the block `ud` refers to. If `ud` represents a link, `nifWaitAlert` completes when an event is received from any device connected to that link. If the descriptor is a session descriptor, the function waits on any event from any attached link.

`nifWaitAlert` waits indefinitely until the NI-FBUS Communications Manager receives an alert with a priority greater than or equal to the input alert priority. Your application can have a dedicated thread which does `nifWaitAlert` only.

When the NI-FBUS Communications Manager interface receives an alert, the `aldata` parameter is filled in with the information about the alert. The form of `aldata->alertData` depends on the value of `aldata->alertType`. `aldata->alarmOrEventName` is the name of the alarm parameter or event parameter that caused the alert. `aldata->deviceTag` and `aldata->blockTag` are the tags of the device and the block of the alarm, respectively.

`nifWaitAlert` sends a confirmation to the device, informing the alerting device that the alert was received. Note that this is a separate step from alert acknowledgment, which must be carried out for alarms using `nifAcknowledgeAlarm`.

If you have multiple threads waiting to receive the same alert, the NI-FBUS Communications Manager sends a copy of the alert to all the waiting threads. Your application must ensure that only one thread acknowledges any one alarm with a call to `nifAcknowledgeAlarm`. You can abort a pending `nifWaitAlert` call by closing the descriptor on which the call was made.

The `alertType` parameter can be `ALERT_ANALOG`, `ALERT_DISCRETE`, or `ALERT_UPDATE`.

`nifAlertData_t` is defined as follows:

```
typedef struct nifAlertData_t{
    uint8          alertType;
    char           deviceTag[TAG_SIZE + 1];
    char           blockTag[TAG_SIZE + 1];
    char           alarmOrEventName [TAG_SIZE + 1];
    uint8          alertKey;
    uint8          standardType;
    uint8          mfrType;
    uint8          messageType;
    uint8          priority;
    nifTime_t      timeStamp;
    uint16         subCode;
    uint16         unitIndex;
    union {
        float      floatAlarmData;
        uint8      discreteAlarmData;
        uint16     staticRevision;
    } alertData;
} nifAlertData_t;
```

Return Values

<code>E_OK</code>	The call was successful.
<code>E_INVALID_DESCRIPTOR</code>	The descriptor you gave is invalid.
<code>E_OBSOLETE_DESC</code>	The input descriptor is no longer valid. It was closed before <code>nifWaitAlert</code> completed.
<code>E_SERVER_CONNECTION_LOST</code>	The session established with the NI-FBUS Communications Manager for this descriptor has been closed or lost.

nifWaitTrend

Purpose

Wait for a trend from a specific device or from any device.

Format

```
nifError_t nifWaitTrend(nifDesc_t ud, nifTrendData_t *trend)
```

Input

`ud` The descriptor of the session, physical device, VFD, block, or link that the trend comes from.

Output

`trend` The information about the specific trend.

Context

Block, VFD, physical device, link, session.

Description

`ud` represents a descriptor of a session, link, physical device, VFD, or block. If `ud` is a VFD descriptor, then the NI-FBUS Communications Manager waits for a trend from any block in the Virtual Field Device. If `ud` is a block, the NI-FBUS Communications Manager waits for a trend from the block `ud` identifies. If `ud` represents a link, the call completes when a trend is received from any device connected to that link. If the descriptor is a session descriptor, `nifWaitTrend` waits on any trend from any attached link.

`nifWaitTrend` waits indefinitely until the NI-FBUS Communications Manager interface receives a trend. Your application can have a dedicated thread which does `nifWaitTrend` only.

When a trend comes in, the `trend` parameter is filled in with the information about the trend. The form of `trend->trendData` depends on the value of `trend->trendType`. There are three trend types: `TREND_FLOAT`, `TREND_DISCRETE` and `TREND_BITSTRING`. If the trend type is `TREND_FLOAT`, the `trend->trendData` is a 16-element array of floating point numbers. If the trend type is `TREND_DISCRETE`, the `trend->trendData` is a 16-element array of 1-byte integers. If the trend type is `TREND_BITSTRING`, the `trend->trendData` is a 16-element array of 2-byte bit strings, which is equivalent to a 32-element array of 1-byte integers. `deviceTag` and `blockTag` are the device and block tags of the parameter that has the trend; `paramName` is the name of the parameter.

If you have multiple threads waiting to receive the same trend, the NI-FBUS Communications Manager sends a copy of the trend to all the waiting threads. You can abort a pending `nifWaitTrend` call by closing the descriptor on which the call was made.

The trend type can be `TREND_FLOAT`, `TREND_DISCRETE`, or `TREND_BITSTRING`. The sample type can be `SAMPLE_INSTANT` or `SAMPLE_AVERAGE`.

`nifTrendData_t` is defined as follows:

```
typedef struct nifTrendData_t {
    uint8 trendType;
    char deviceTag[TAG_SIZE + 1];
    char blockTag[TAG_SIZE + 1];
    char paramName[TAG_SIZE + 1];
    uint8 sampleType;
    uint32 sampleInterval;
    nifTime_t lastUpdate;
    uint8 status[16];
    union {
        float f[16];
        uint8 d[16];
        uint8 bs[32];
    } trendData;
} nifTrendData_t;
```

Return Values

<code>E_OK</code>	The call was successful.
<code>E_INVALID_DESCRIPTOR</code>	The descriptor you gave is not valid.
<code>E_SERVER_CONNECTION_LOST</code>	The session established with the NI-FBUS Communications Manager for this descriptor has been closed or lost.

Technical Support and Professional Services

Visit the following sections of the National Instruments Web site at ni.com for technical support and professional services:

- **Support**—Online technical support resources include the following:
 - **Self-Help Resources**—For immediate answers and solutions, visit our extensive library of technical support resources available in English, Japanese, and Spanish at ni.com/support. These resources are available for most products at no cost to registered users and include software drivers and updates, a KnowledgeBase, product manuals, step-by-step troubleshooting wizards, hardware schematics and conformity documentation, example code, tutorials and application notes, instrument drivers, discussion forums, a measurement glossary, and so on.
 - **Assisted Support Options**—Contact NI engineers and other measurement and automation professionals by visiting ni.com/ask. Our online system helps you define your question and connects you to the experts by phone, discussion forum, or email.
- **Training**—Visit ni.com/custed for self-paced tutorials, videos, and interactive CDs. You also can register for instructor-led, hands-on courses at locations around the world.
- **System Integration**—If you have time constraints, limited in-house technical resources, or other project challenges, NI Alliance Program members can help. To learn more, call your local NI office or visit ni.com/alliance.

If you searched ni.com and could not find the answers you need, contact your local office or NI corporate headquarters. Phone numbers for our worldwide offices are listed at the front of this manual. You also can visit the Worldwide Offices section of ni.com/niglobal to access the branch office Web sites, which provide up-to-date contact information, support phone numbers, email addresses, and current events.

Glossary

A

Address	Character code that identifies a specific location (or series of locations) in memory.
Administrative function	An NI-FBUS function that deals with administrative tasks, such as returning descriptors and closing descriptors.
Alarm	A notification the NI-FBUS Communications Manager software sends when it detects that a block leaves or returns to a particular state.
Alert	An alarm or event.
Alert function	A function that receives or acknowledges an alert.
Application	Function blocks.
Argument	A value you pass in a function call. Sometimes referred to as a parameter, but this documentation uses a different meaning for parameter, which is included in this glossary.
Array	Ordered, indexed list of data elements of the same type.
Attribute	Properties of parameters.

B

Bit string	A data type in the object description.
Block	A logical software unit that makes up one named copy of a block and the associated parameters its block type specifies. The values of the parameters persist from one invocation of the block to the next. It can be a resource block, transducer block, or function block residing within a virtual field device.
Block tag	A character string name that uniquely identifies a block on a Fieldbus network.
Boolean	Logical relational system having two values, each the opposite of the other, such as true and false or zero and one.

Bridge	An interface in a Fieldbus network between two different protocols.
Buffer	Temporary storage for acquired or generated data.
Bus	The group of conductors that interconnect individual circuitry in a computer. Typically, a bus is the expansion vehicle to which I/O or other devices are connected. Examples of PC busses are the ISA and PCI buses.

C

Character string name	See Tag .
Core function	A basic function that the NI-FBUS Communications Manager software performs, such as reading and writing block parameters.

D

DD	See Device Description.
DDOD	Device Description Object Dictionary. The Device Description binary file.
DDS	See Device Description Service.
Descriptor	A number returned to the application by the NI-FBUS Communications Manager, used to specify a target for future NI-FBUS calls.
Device	A sensor, actuator, or control equipment attached to the Fieldbus.
Device Description	A machine-readable description of all the blocks and block parameters of a device.
Device Description Service	A set of functions that applications use to access Device Descriptions.
Device ID	An identifier for a device that the manufacturer assigns. No two devices can have the same device ID.
Device tag	A name you assign to a Fieldbus device.
DLL	See Dynamic Link Library.
DMA	Direct Memory Access.
Dynamic Link Library	A library of functions and subroutines that links to an application at run time.

E

Event An occurrence on a device that causes a Fieldbus entity to send the Fieldbus event message.

F

Field device A Fieldbus device connected directly to a Fieldbus.

Fieldbus An all-digital, two-way communication system that connects control systems to instrumentation. A process control local area network defined by ISA standard S50.02.

Fieldbus Foundation An organization that developed a Fieldbus network specifically based upon the work and principles of the ISA/IEC standards committees.

Fieldbus Messaging Specification The layer of the communication stack that defines a model for applications to interact over the Fieldbus. The services FMS provides allow you to read and write information about the OD, read and write the data variables described in the OD, and perform other activities such as uploading/downloading data and invoking programs inside a device.

FMS *See* Fieldbus Messaging Specification.

Foundation Fieldbus specification The communications network specification that the Fieldbus Foundation created.

Function block A named block consisting of one or more input, output, and contained parameters. The block performs some control function as its algorithm. Function blocks are the core components you control a system with. The Fieldbus Foundation defines standard sets of function blocks. There are ten function blocks for the most basic control and I/O functions. Manufacturers can define their own function blocks.

Function block application The block diagram that represents your control strategy.

H

Header file A C-language source file containing important definitions and function prototypes.

I

Index An integer that the Fieldbus specification assigns to a Fieldbus object or a device that you can use to refer to the object. A value in the object dictionary used to refer to a single object.

L

LAS Link Active Scheduler.

Link A Foundation Fieldbus network is made up of devices connected by a serial bus. This serial bus is called a link (also known as a segment).

Link ID *See* Link identifier.

Link identifier A number that specifies a link.

Live list The list of all devices that are properly responding to the Pass Token.

M

Mode Type of communication.

N

NI-FBUS Communications Manager Software shipped with National Instruments Fieldbus interfaces that lets you read and write values. It does not include configuration capabilities.

O

Object An element of an object dictionary.

Object attribute A part of the machine-readable description of a Fieldbus object.

Object description Describes data that is communicated over the Fieldbus.

Object Dictionary A structure in a device that describes data that can be communicated on the Fieldbus. The object dictionary is a lookup table that gives information such as data type and units about a value that can be read from or written to a device.

Object value The actual data value associated with a Fieldbus object.

Octet A single 8-bit value.

OD *See* [Object Dictionary](#).

P

Parameter One of a set of network-visible values that makes up a function block.

Physical device A single device residing at a unique address on the Fieldbus.

Physical device tag A user-defined name for a physical device.

Program A set of instructions the computer can follow, usually in a binary file format, such as a `.exe` file.

R

Resource block A special block containing parameters that describe the operation of the device and general characteristics of a device, such as manufacturer and device name. Only one resource block per device is allowed.

S

Segment *See* [Link](#).

Server Device that receives a message request.

Service Services allow user applications to send messages to each other across the Fieldbus using a standard set of message formats.

Session A communication path between an application and the NI-FBUS Communications Manager.

Symbol file A Fieldbus Foundation or device manufacturer-supplied file that contains the ASCII names for all the objects in a device.

T

Tag	A name you can define for a block, virtual field device, or device.
Thread	An operating system object that consists of a flow of control within a process. In some operating systems, a single process can have multiple threads, each of which can access the same data space within the process. However, each thread has its own stack and all threads can execute concurrently with one another (either on multiple processors, or by time-sharing a single processor).
Timeout	A period of time after which an error condition is raised if some event has not occurred.
Transducer block	A block that is an interface to the physical, sensing hardware in the device. It also performs the digitizing, filtering, and scaling conversions needed to present input data to function blocks and converts output data from function blocks. Transducer blocks decouple the function blocks from the hardware details of a given device, allowing generic indication of function block input and output. Manufacturers can define their own transducer blocks.
Trend	A Fieldbus object that allows a device to sample a process variable periodically, then transmit a history of the values on the network.
Trend function	An NI-FBUS call related to trends.

V

Variable list	A list of variables you can access with a single Fieldbus transaction.
VFD	<i>See</i> Virtual Field Device.
Virtual Field Device	The virtual field device is a model for remotely viewing data described in the object dictionary. The services provided by the Fieldbus Messaging Specification allow you to read and write information about the object dictionary, read and write the data variables described in the object dictionary, and perform other activities such as uploading/downloading data and invoking programs inside a device. A model for remotely viewing data described in the object dictionary.

Index

A

administrative functions

list of functions (table), 1-1

nifClose, 1-2

nifDownloadDomain, 1-3

nifGetBlockList, 1-4

nifGetDeviceList, 1-6

nifGetInterfaceList, 1-8

nifGetVFDList, 1-10

nifOpenBlock, 1-12

nifOpenLink, 1-14

nifOpenPhysicalDevice, 1-16

nifOpenSession, 1-18

nifOpenVfd, 1-19

alert and trend functions

list of functions (table), 3-1

nifAcknowledgeAlarm, 3-2

nifWaitAlert, 3-4

nifWaitTrend, 3-6

C

contacting National Instruments, A-1

conventions used in the manual, *vi*

core functions

list of functions (table), 2-1

nifFreeObjectAttributes, 2-2

nifFreeObjectType, 2-3

nifGetObjectAttributes, 2-4

nifGetObjectName, 2-7

nifGetObjectSize, 2-10

nifGetObjectType, 2-12

nifReadObject, 2-18

nifReadObjectList, 2-21

nifWriteObject, 2-24

using NI-FBUS interface macros, 2-27

customer

education, A-1

professional services, A-1

technical support, A-1

D

diagnostic resources, A-1

documentation

online library, A-1

drivers

instrument, A-1

software, A-1

E

example code, A-1

F

frequently asked questions, A-1

H

help

professional services, A-1

technical support, A-1

I

instrument drivers, A-1

interface macros, NI-FBUS, 2-27

K

KnowledgeBase, A-1

N

National Instruments

- customer education, A-1
- professional services, A-1
- system integration services, A-1
- technical support, A-1
- worldwide offices, A-1

- nifAcknowledgeAlarm function, 3-2
- nifClose function, 1-2
- nifDownloadDomain function, 1-3
- nifFreeObjectAttributes function, 2-2
- nifFreeObjectType function, 2-3
- nifGetBlockList function, 1-4
- nifGetDeviceList function, 1-6
- nifGetInterfaceList function, 1-8
- nifGetObjectAttributes function, 2-4
- nifGetObjectName function, 2-7
- nifGetObjectSize function, 2-10
- nifGetObjectType function, 2-12
 - context, 2-13
 - data structure, 2-14
 - data type, 2-14
 - description, 2-13
 - format, 2-12
 - input, 2-13
 - object code elements, 2-14
 - object codes for the `nifObjTypeList_t`
 - data structure (table), 2-14, 2-16
 - output, 2-13
 - pseudocode for getting type information, 2-15
 - purpose, 2-12
 - return values, 2-16
 - standard data types for `ODT_SIMPLETYPE`
 - object code (table), 2-16
 - typeIndex of elements, 2-15
- nifGetVFDFList function, 1-10
- nifOpenBlock function, 1-12
- nifOpenLink function, 1-14
- nifOpenPhysicalDevice function, 1-16

- nifOpenSession function, 1-18
- nifOpenVfd function, 1-19
- nifReadObject function, 2-18
- nifReadObjectList function, 2-21
- nifWaitAlert function, 3-4
- nifWaitTrend function, 3-6
- nifWriteObject function, 2-24

O

- online technical support, A-1

P

- phone technical support, A-1
- professional services, A-1
- programming examples, A-1

R

- related documentation, 1-1

S

- software drivers, A-1
- support
 - technical, A-1
- system integration services, A-1

T

- technical support, A-1
- telephone technical support, A-1
- training
 - customer, A-1
- troubleshooting resources, A-1

W

Web

- professional services, A-1
- technical support, A-1
- worldwide technical support, A-1