

RELEASE NOTES

NI Vision Acquisition Software

This document describes how to install and configure NI Vision Acquisition Software. NI Vision Acquisition Software allows you to acquire, display, and save images; control the digital I/O on IEEE 1394 hardware; and configure your drivers and hardware. NI Vision Acquisition Software includes the following features:

- **NI-IMAQ 3.6**—The latest generation driver in the NI Vision product line. Using NI-IMAQ you can program your image acquisition device to acquire, display, and save images.
- **NI-IMAQ for IEEE 1394 Cameras 2.0.3**—The National Instruments driver software for IEEE 1394 cameras. NI-IMAQ for IEEE 1394 Cameras gives you the ability to use IEEE 1394 industrial digital video cameras to acquire images.
- **NI-IMAQ I/O 2.0**—The National Instruments I/O device driver software for controlling the digital I/O on IEEE 1394 hardware.
- **NI Measurement & Automation Explorer (MAX) 4.1**—The National Instruments graphical configuration utility you can use to configure NI software and hardware, execute system diagnostics, add new channels and interfaces, and view the devices you have connected to your computer.

There is a `readme.rtf` file for each NI Vision Acquisition Software driver. The `readme.rtf` files are installed in the following default locations:

- NI-IMAQ—`<National Instruments>\NI-IMAQ\Docs\readme.rtf`, where `<National Instruments>` is the location to which National Instruments software is installed.
- NI-IMAQ for IEEE 1394 Cameras—`<National Instruments>\NI-IMAQ for IEEE-1394\Docs\readme.rtf`.
- NI-IMAQ I/O—`<National Instruments>\NI-IMAQ IO\Docs\readme.rtf`.

Refer to the `readme.rtf` files for late-breaking information and known issues.

New Features

This release of NI-IMAQ includes the following features:

- Support for LabVIEW 8.2.

This release of NI-IMAQ for IEEE 1394 Cameras includes the following features:

- Support for LabVIEW 8.2.

This release of NI-IMAQ I/O includes the following features:

- Support for the NI PCIe-8255R device.
- Support for DMA Input and Output.
- Support for LabVIEW 8.2 and the LabVIEW 8.2 FPGA Module.

Minimum System Requirements

The development computer must meet the following requirements to run NI Vision Acquisition Software:

- Pentium III 750 MHz processor
- 256 MB RAM
- 300 MB of free hard disk space
- 1024 × 768 resolution video adapter and monitor
- Internet Explorer 5.0 or later to view online documentation

Software Components

NI Vision Acquisition Software contains the following components:

- NI-IMAQ 3.6
 - NI-IMAQ device driver software, with user libraries and sample code
 - Documentation
- NI-IMAQ for IEEE 1394 Cameras 2.0.3
 - NI-IMAQ for IEEE 1394 Cameras device driver software, with user libraries and sample code
 - Documentation

- ❑ NI-IMAQ I/O 2.0
 - NI-IMAQ I/O device driver software, with user libraries and sample code
 - Documentation
- ❑ NI Measurement & Automation Explorer 4.1

Software Support

This section describes the operating systems and application development environments (ADEs) supported by NI-IMAQ, NI-IMAQ for IEEE 1394 Cameras, and NI-IMAQ I/O.

NI-IMAQ, NI-IMAQ for IEEE 1394 Cameras, and NI-IMAQ I/O support the following operating systems:

- Windows 2000/XP
- LabVIEW Real-Time Module 7.1.1 or later

NI-IMAQ, NI-IMAQ for IEEE 1394 Cameras, and NI-IMAQ I/O support the following ADEs:

- LabVIEW 7.1.1 or later
- LabVIEW Real-Time Module 7.1.1 or later
- LabWindows™/CVI™ 6.0 or later
- Microsoft Visual C/C++ 6.0 or later
- Microsoft Visual Basic 6.0 or later

NI-IMAQ for IEEE 1394 Cameras and NI-IMAQ I/O also support Microsoft Visual Studio .NET 2003.

You can also use NI-IMAQ, NI-IMAQ for IEEE 1394 Cameras, and NI-IMAQ I/O with the NI Vision Development Module 7.0 or later and NI Vision Builder for Automated Inspection (Vision Builder AI) 2.5 or later to prototype, benchmark, and deploy your applications.

Considerations for NI-IMAQ I/O Devices

The following sections provide specific information about updating your software for use with your NI-IMAQ I/O device. NI-IMAQ I/O devices include the NI CVS-1450 Series compact vision system, the NI PCI-8254R, and the NI PCIe-8255R.

Vision Builder for Automated Inspection

If you are using Vision Builder AI with your CVS-1450 device, you must have Vision Builder AI 2.5 or later installed. If you have Vision Builder AI 2.0 installed, go to ni.com/support, and click the **Drivers and Updates** link to find and install the latest downloadable update. Without this support, you cannot configure the CVS-1450 device. Refer to the Vision Builder AI `readme.txt` file for additional information about this update.

Upgrading NI-IMAQ I/O Host VIs for Use with LabVIEW 8.x

A host VI is a VI that communicates with an FPGA VI to control an FPGA target. A host VI can run on a Windows computer or on a real-time (RT) target. If you previously used LabVIEW 7.x to program your NI-IMAQ I/O device and you upgrade to LabVIEW 8.x, host VIs that use the digital I/O functionality of the NI-IMAQ I/O device may have a broken **Run** arrow when you open the VIs in LabVIEW 8.x.

Complete the following steps to correct the broken **Run** arrow:

1. In LabVIEW 8.x, select **Tools»Update 7.X VIs using NI-IMAQ I/O** in the Getting Started window or in the Project Explorer window of an open project.
2. Click **Add** to add the host VIs that you want to upgrade to the **VIs** list.
3. Choose the location to save the VIs.
4. Click **Continue**. The **Update 7.X VIs using NI-IMAQ I/O** window will automatically close when the update is complete.

Upgrading FPGA VIs for Use with LabVIEW 8.x

An FPGA VI is a VI that runs on an FPGA target. If you created FPGA VIs using LabVIEW 7.x and the LabVIEW FPGA Module 1.x, you can update the VIs for use with LabVIEW 8.x and the LabVIEW 8.x FPGA Module. Refer to *Upgrading FPGA VIs, Host VIs, and Embedded Projects from LabVIEW FPGA Module 1.x to 8.x* in the *LabVIEW Help* for more information about upgrading FPGA VIs to LabVIEW 8.x.

Installation

Complete the following steps to install NI Vision Acquisition Software:



Note You must have administrator access to install the NI Vision Acquisition Software.

1. Insert the NI Vision Acquisition Software installation CD in the CD-ROM drive.

2. If you do not have autorun enabled, double-click `autorun.exe`. If you have autorun enabled, `autorun.exe` runs automatically.
3. Follow the onscreen instructions.

NI-IMAQ and NI-IMAQ for IEEE 1394 Cameras integrate with MAX, the National Instruments utility for configuring and testing your measurement and automation system. The MAX icon appears on your desktop after you install NI Vision Acquisition Software.

Configuring NI-IMAQ

Complete the following steps to install an image acquisition device and configure NI-IMAQ:



Note You must install NI-IMAQ before installing your image acquisition device.



Caution Power off and unplug the computer before installing your hardware. Wait for any motherboard LEDs to power off before proceeding, since some computers remain powered for some time after being unplugged.

1. Install your image acquisition device, and connect the camera. Refer to the device documentation for specific hardware installation instructions.



Note If you have to manually associate the image acquisition device with the NI-IMAQ driver software, Windows may return a warning stating that the driver is unsigned. It is safe to ignore the warning.

2. Run MAX.



- a. Double-click the MAX icon on the desktop. You can use MAX to modify camera properties. Once you have saved these properties, they become the default settings for all NI-IMAQ applications.
- b. Expand **Devices and Interfaces** and **NI-IMAQ Devices** to display a list of the image acquisition devices installed on your computer.

Only one application can access the image acquisition device at any given time. Selecting an image acquisition device in MAX opens a session to the device, and the open session prevents other applications from accessing the device. To allow applications to access an image acquisition device, deselect the device in MAX to close the session.

If you are using a Camera Link image acquisition device with NI-IMAQ 3.5 or later, you can simultaneously open a session to the device in an application and use a camera control utility by using `clallserial.dll`.

3. Select a camera file, and acquire an image.

- a. Click the plus sign next to the image acquisition device to expand the menu tree and list the available channels or ports. Right-click the channel or port to display a list of available cameras.
- b. Select the appropriate camera type from the list. Camera type selection varies according to the image acquisition device installed.
- c. To change the camera settings, modify the parameters at the bottom of the image viewer panel.
- d. Click the **Snap** button on the toolbar to acquire an image.





- e. Click the **Grab** button on the toolbar to acquire images continuously. A grab allows you to focus the camera.



Tip For a complete list of supported cameras, right-click the channel or port, select **Camera**, and click **Search ni.com**.



Note Refer to the right side of the MAX user interface, which displays context-sensitive help, for information about configuring image acquisition devices with MAX.

Configuring a Remote NI Image Acquisition Device

Use MAX to install NI-IMAQ for LabVIEW Real-Time from the host machine onto the target system. The NI-IMAQ for LabVIEW Real-Time components enable the remote device to acquire and analyze images as directed by the host machine.



Note Install NI-IMAQ and the LabVIEW Real-Time Module on the remote system before you install and configure the image acquisition device. Follow the steps in the MAX help window to install software.



Tip Configuring remote image acquisition devices is similar to configuring local image acquisition devices, except that the procedure for working with camera files is different. Refer to the *Measurement & Automation Explorer Help for IMAQ* for information about working with camera files on remote image acquisition devices.

1. Launch MAX.
2. Expand **Remote Systems**.

3. Expand the appropriate system.
4. Expand **Devices and Interfaces**.
5. Expand **NI-IMAQ Devices**.
6. Expand the device you want to configure.

Refer to the *Measurement & Automation Explorer Help for IMAQ* for information about configuring specific NI image acquisition devices. You can access this help file from the **MAX Help** menu by selecting **Help»Help Topics»NI-IMAQ**.

Configuring NI-IMAQ for IEEE 1394 Cameras

Complete the following steps to install IEEE 1394 hardware and configure NI-IMAQ for IEEE 1394 Cameras.

Instructions for configuring an IEEE 1394 image acquisition device are included in the *NI-IMAQ for IEEE 1394 Cameras Help*. You can access this help file from the **MAX Help** menu by selecting **Help»Help Topics»NI-IMAQ IEEE 1394**.

Installing IEEE 1394 Hardware

Install your IEEE 1394 adapter card. Follow the installation instructions provided by the manufacturer.

Configuring NI-IMAQ for IEEE 1394 Cameras for Windows

If you are using Windows 2000/XP, complete the following steps to configure NI-IMAQ for IEEE 1394 Cameras:

1. Connect the IEEE 1394 camera.

2. Run MAX.



- a. Double-click the MAX icon on your desktop. You can use MAX to modify camera attributes. After you have saved these attributes, they become the default settings for all NI-IMAQ for IEEE 1394 Cameras or NI Vision applications.
- b. Expand **Devices and Interfaces»NI-IMAQ IEEE 1394 Devices** in the configuration tree to display a list of the cameras installed on your computer.
- c. If your camera does not show up as an NI-IMAQ IEEE 1394 digital camera, change the associated driver by right-clicking the camera and selecting **Driver»NI-IMAQ IEEE 1394 IIOC Digital Camera**.
- d. Select the camera from the list. You then can view or modify the camera attributes on the **Camera Attributes** tab located below the image viewer.



Tip Click the **Show Help** button to display the help window on the right side of the image viewer. Move your mouse over the properties to view context-sensitive help in the bottom half of the help window.

Configuring NI-IMAQ for IEEE 1394 Cameras for the LabVIEW Real-Time Module

If you are using a Windows development machine, the LabVIEW Real-Time Module, and an RT target, complete the following steps to install and configure NI-IMAQ for IEEE 1394 Cameras:

1. Install NI-IMAQ for IEEE 1394 Cameras software on your Windows development machine.

2. Ensure that your RT target is connected to the same subnet as the Windows development machine.
3. Run MAX.
 - a. Double-click the MAX icon on your desktop.
 - b. Expand the **Remote Systems** list in the configuration tree.
 - c. Select your RT target in the list.
 - d. Configure your network settings. Refer to the *Remote Systems Help* in MAX (**Help»Help Topics»Remote Systems**) for instructions about configuring network settings.
4. Install NI-IMAQ for IEEE 1394 Cameras on the RT target.
 - a. Click the **Software** item below the RT target in the configuration tree.
 - b. Click **Install Software** on the MAX toolbar to launch the LabVIEW Real-Time Install Software Wizard.
 - c. Select **NI-IMAQ for IEEE 1394 RT**, as well as any additional software you would like to install on the target machine.
 - d. Click **Next**. Review the list of software you selected to install.
 - e. Click **Next** to begin downloading the software to the target machine. When MAX has finished downloading the software, it restarts the remote device.
 - f. Click **Finish**.
5. Connect your camera to your remote system.





Note If you are using a CVS-1450 device with Vision Builder AI, refer to the Vision Builder AI documentation for camera configuration information.

6. Press <F5> to refresh the MAX configuration tree. Your IEEE 1394 camera should be listed in the **Remote Systems** list.




Tip Press <F5> to refresh the configuration tree whenever you connect a new device to an RT target.

7. Expand **Devices and Interfaces»NI-IMAQ IEEE 1394 Devices** in the configuration tree to display a list of the cameras installed on your computer.
8. Select the camera from the list. You then can view or modify the camera attributes from the **Camera Attributes** panel located below the image viewer.

Using the MAX Toolbar


The following list describes the functions of the toolbar buttons in MAX.



- Click **Save** to save the current acquisition configuration.




- Click **Revert** to reset the configuration values to those of the last saved configuration.




- Click **Snap** to acquire and display a single image.




- Click **Grab** to acquire and display a continuous set of images, which is useful for example, when you need to focus the camera.



- Click **Histogram** to display a histogram of the captured image.



- Click **Save Image** to save the image.



- Click **Show/Hide Help** to display/hide the topic and context-sensitive help to the right of the image viewer.

Documentation

The NI Vision Acquisition Software documentation is installed onto your hard drive with NI Vision Acquisition Software. The documentation ships as Adobe Acrobat portable document format (PDF) files and HTML Help files.

To view the NI Vision Acquisition Software documentation, select **Start» All Programs»National Instruments»Vision»Documentation**. You can access the *NI-IMAQ VI Reference Help* and the *NI-IMAQ for IEEE 1394 Cameras VI Reference Help* from the LabVIEW **Help** menu.



Note You must have Adobe Acrobat Reader with Search and Accessibility 5.0.5 or later installed to view the PDFs. Refer to the Adobe Systems Incorporated Web site at www.adobe.com to download Adobe Reader.

National Instruments, NI, ni.com, and LabVIEW are trademarks of National Instruments Corporation. Refer to the *Terms of Use* section on ni.com/legal for more information about National Instruments trademarks. Other product and company names mentioned herein are trademarks or trade names of their respective companies. For patents covering National Instruments products, refer to the appropriate location: **Help»Patents** in your software, the `patents.txt` file on your CD, or ni.com/patents.

© 2005–2006 National Instruments Corporation. All rights reserved.