

Manufacturer: National Instruments

Board Assembly Part Numbers (Refer to Procedure 1 for identification procedure):

Part Number and Revision	Description
190100x-01L	NI PXI-5122, 8MB/CH
190100x-02L	NI PXI-5122, 32MB/CH
190100x-03L	NI PXI-5122, 256MB/CH
190100x-04L	NI PXI-5122, 512MB/CH
190971x-01L	NI PCI-5122, 8MB/CH
190971x-02L	NI PCI-5122, 32MB/CH
190971x-03L	NI PCI-5122, 256MB/CH
195945x-01L	NI PXIe-5122, 8MB/CH
195945x-02L	NI PXIe-5122, 64MB/CH
195945x-03L	NI PXIe-5122, 256MB/CH

Volatile Memory

<i>Target Data</i>	<i>Type</i>	<i>Size</i>	<i>Battery Backup</i>	<i>User¹ Accessible</i>	<i>System Accessible</i>	<i>Sanitization Procedure</i>
PCI Communication	PCI Switch	208 b	No	Yes	No	Cycle Power
Memory Control, Data Buffer	FPGA Block RAM	Xilinx XCV200E (PCI/PXI) Xilinx XC2V1000 (PCI/PXI) Altera EP2S90 (PXIe)	No	Yes	No	Cycle Power
Waveform Data	Synchronous DRAM	16 MB, 64 MB, 128 MB, 512 MB, or 1 GB	No	Yes	No	Cycle Power

Non-Volatile Memory (incl. Media Storage)

<i>Target Data</i>	<i>Type</i>	<i>Size</i>	<i>Battery Backup</i>	<i>User Accessible</i>	<i>System Accessible</i>	<i>Sanitization Procedure</i>
Boot ROM, PCI bus loading, enumeration	EEPROM	8 kB (PCI/PXI) 32 MB (PXIe)	No	No	Yes	None
Device configuration	EEPROM	4 Kb	No	No	Yes	None
• Device information				Yes	Yes	Procedure 2
• Calibration metadata				No	Yes	None
• Calibration data ²				No	Yes	None
FPGA programming	CPLD	Altera EPM7064 (PCI/PXI)	No	No	Yes	None

¹ Refer to *Terms and Definitions* section for clarification of *User* and *System Accessible*

² Calibration constants that are stored on the device include information for the device's full operating range. Any implications resulting from partial self-calibration can be eliminated by running the full self-calibration procedure.

Procedures

Procedure 1 –Board Assembly Part Number Identification:

To determine the Board Assembly Part Number and Revision, refer to the label applied to the surface of your product. The Assembly Part Number should be formatted as “P/N: #####X-##L

Procedure 2 - Device Configuration EEPROM (Calibration Metadata):

The user-accessible areas of the Device Configuration EEPROM are exposed through a calibration Applications Programming Interface (API) in LabVIEW. To clear the calibration meta-data area, complete the following steps:

1. To clear the calibration password, from LabVIEW use niScope Cal Change Password.vi to overwrite the password.
2. To clear the user-defined information, from LabVIEW use niScope Cal Store Misc Info.vi to overwrite user-defined information.

Terms and Definitions

Cycle Power:

The process of completely removing power from the device and its components and allowing for adequate discharge. This process includes a complete shutdown of the PC and/or chassis containing the device; a reboot is not sufficient for the completion of this process.

Volatile Memory:

Requires power to maintain the stored information. When power is removed from this memory, its contents are lost. This type of memory typically contains application specific data such as capture waveforms.

Non-Volatile Memory:

Power is not required to maintain the stored information. Device retains its contents when power is removed. This type of memory typically contains information necessary to boot, configure, or calibrate the product or may include device power up states.

User Accessible:

The component is read and/or write addressable such that a user can store arbitrary information to the component from the host using a publicly distributed NI tool, such as a Driver API, the System Configuration API, or MAX.

System Accessible:

The component is read and/or write addressable from the host without the need to physically alter the product.

Clearing:

Per *NIST Special Publication 800-88 Revision 1*, “clearing” is a logical technique to sanitize data in all User Accessible storage locations for protection against simple non-invasive data recovery techniques using the same interface available to the user; typically applied through the standard read and write commands to the storage device.

Sanitization:

Per *NIST Special Publication 800-88 Revision 1*, “sanitization” is a process to render access to “Target Data” on the media infeasible for a given level of effort. In this document, clearing is the degree of sanitization described.