


EMI REDUCTION FOR VXI 1200 FLEXFRAME™

To reduce electromagnetic interference (EMI) emanating from your VXI-1394, VXI-1394/G, or VXIpc-740 series controller in your VXI 1200 FlexFrame, install the soft-shield gasket, included in your kit, as shown below.

1. Partially eject controller. Pull away from FlexFrame to create a gap.
2. Insert gasket in gap between FlexFrame and controller.
3. Close injector handles on controller to reduce gap with gasket in place.



1 Gap at Edge of FlexFrame	3 Gap at Edge of Controller	5 VXI 1200 FlexFrame
2 Gasket	4 Controller	

Figure 1. Install gasket between FlexFrame and controller



Note It may be necessary to trim gasket length to fit between FlexFrame and controller.